

KODAK X-OMAT 270 RA Processor



HEALTH SCIENCES

PLEASE NOTE

The information contained herein is based on the experience and knowledge relating to the subject matter gained by Eastman Kodak Company prior to publication.

No patent license is granted by this information.

Eastman Kodak Company reserves the right to change this information without notice, and makes no warranty, express or implied, with respect to this information. Kodak shall not be liable for any loss or damage, including consequential or special damages, resulting from the use of this information, even if loss or damage is caused by Kodak's negligence or other fault.

CAUTION



This equipment includes parts and assemblies sensitive to damage from electrostatic discharge. Use caution to prevent damage during all service procedures.


Table of Contents


Description	Page
Locators	1-1
Covers and Panels	2-1
Covers and Panels - Receive End View	2-3
Covers and Panels - Feed End View	2-5
Receiving Bin Hardware	2-7
Top Cover Hardware - New Style	2-9
Top Cover Hardware - Old Style, Left Side	2-11
Top Cover Hardware - Old Style, Right Side	2-13
Internal Covers	2-15
Roller Transport System	3-1
Complete Rack and Crossover Assemblies	3-3
Detector Crossover	3-5
Detector Crossover - Drive Side	3-7
Detector Crossover - Non-Drive Side	3-9
Developer Rack Assembly	3-10
Developer Rack - Roller Assemblies	3-11
Developer Rack - Exit Rollers	3-13
Developer Rack - Other Rollers	3-15
Developer Rack - Master Rollers	3-17
Developer Rack - Guide Shoes	3-19
Developer/Fixer Crossover Assembly	3-21
Developer/Fixer Crossover - Drive Side	3-23
Developer/Fixer Crossover - Non-Drive Side	3-25
Fixer Rack Assembly	3-26
Fixer Rack - Roller Assemblies	3-27
Fixer Rack - Exit Rollers	3-29
Fixer Rack - Other Rollers	3-31
Fixer Rack - Master Rollers	3-33
Fixer Rack - Guide Shoes	3-35
Fixer/Wash Crossover Assembly	3-37
Fixer/Wash Crossover - Drive Side	3-39
Fixer/Wash Crossover - Non-Drive Side	3-41

Description	Page
Wash Rack Assembly - Mod 17 Not Installed	3-42
Wash Rack, Mod 17 Not Installed - Roller Assemblies.....	3-43
Wash Rack, Mod 17 Not Installed - Top Rollers	3-45
Wash Rack, Mod 17 Not Installed - Other Rollers	3-47
Wash Rack, Mod 17 Not Installed - Guide Shoes.....	3-49
Wash Rack Assembly - Mod 17 Installed	3-50
Wash Rack, Mod 17 Installed - Roller Assemblies.....	3-51
Wash Rack, Mod 17 Installed - Top Rollers.....	3-53
Wash Rack, Mod 17 Installed - Other Rollers	3-55
Wash Rack, Mod 17 Installed - Guide Shoes.....	3-57
Dryer Rack Assembly	3-58
Dryer Rack - Roller Assemblies	3-59
Dryer Rack - Air Tubes.....	3-61
Dryer Rack - Squeegee Rollers	3-63
Dryer Rack - Other Rollers, 1 of 2	3-65
Dryer Rack - Other Rollers, 2 of 2	3-67
Dryer Rack - Drive Chain Cover and Plenum.....	3-69
Top Exit Rack	3-71
Top Exit Rack With Mod 10 or Mod 13 Installed.....	3-73
Top Exit Rack With Mod 13 Installed.....	3-75
Top Exit Rack With Mod 10 Installed, Without Mod 13 Installed	3-77
Main Drive Assembly	4-1
Main Drive Shaft	4-3
Main Drive Motor	4-5
Dryer Assembly	5-1
Dryer Assembly	5-3
Plumbing	6-1
Heat Exchanger	6-3
Solution Thermowell	6-5
Recirculation Pump Assembly.....	6-7
Replenishment Pump Assembly.....	6-9
Mandrel Filter Assembly	6-11
Bulkhead Fittings	6-13
Developer Plumbing Diagram.....	6-15
Fixer Plumbing Diagram.....	6-17
Wash Plumbing Diagram.....	6-19
Electrical	7-1
Detector Switches.....	7-3
Electrical Box	7-5
Interface Panel and Receptacle Panel.....	7-7
Microprocessor Board.....	7-9
Display Board Assembly.....	7-11
Dryer Over-Temperature Thermostat	7-13
Miscellaneous Electrical Parts Panel	7-15
Miscellaneous	8-1
Leveling Feet	8-3
Accessories.....	8-5
Miscellaneous Tank Assembly	8-7
Electrical Box Slides	8-9
Numerical Index	9-1
Alphabetical Index	10-1


Description	Page
Publication Change Table	11-1

SECTION 1 Locators





H104_0061DCB
P104_0061DA




H104 0419DCA
H104 0419DA

BLANK PAGE

SECTION 2
Covers and Panels

Table of Contents

Description	Page
Covers and Panels - Receive End View	2-3
Covers and Panels - Feed End View	2-5
Receiving Bin Hardware	2-7
Top Cover Hardware - New Style	2-9
Top Cover Hardware - Old Style, Left Side	2-11
Top Cover Hardware - Old Style, Right Side	2-13
Internal Covers	2-15




H104_0424ECA
H104_0424EA

Figure 2-1 Covers and Panels - Receive End View
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	968797	Tray - Receive	1	Includes Receive Tray 968797.
2	968798	Cover - Top	1	
3	719488	Symbol - Corporate.....	1	
4	779393	Panel - Exit	1	
5	779336	Bin - Receiving, Film Exit	1	
6	324726	Latch Assembly.....	1	
7	914893	Panel - Front, Stand	1	
8	914891	Panel - Side, Stand.....	1	
9	779394	Panel - Access, Non-Drive Side	1	
10	779335	Label - Identification.....	1	

Figure 2-1 Covers and Panels - Receive End View
Order by Part Number




H104_0126DCB
P104_0126DA

Figure 2-2 Covers and Panels - Feed End View
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	779395	Panel - Feed End.....	1	
2	914747	Shelf - Feed	1	
3	779398	Panel - Access, Feed End.....	1	
4	914892	Panel - Rear, Stand.....	1	
5	914891	Panel - Side, Stand.....	1	
6	779396	Panel - Access, Drive Side.....	1	

Figure 2-2 Covers and Panels - Feed End View
Order by Part Number




H104_0108ECA
H104_0108EA

Figure 2-3 Receiving Bin Hardware
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	911719	Spring - Hinge, Drive Side.....	1	
2	136224	E-Ring	2	
3	619284	Screw	8	
4	852961	Washer - Lock.....	8	
5	852616	Washer	8	
6	911713	Bracket - Hinge	2	
7	911716	Pin - Hinge	2	
8	911714	Plate - Hinge, Drive Side	1	
9	911717	Hinge - Nut Plate	2	
10	911715	Plate - Hinge, Non-Drive Side	1	
11	911720	Spring - Hinge, Non-Drive Side	1	

Figure 2-3 Receiving Bin Hardware
Order by Part Number




H104_0408ECA
H104_0408EA

Figure 2-4 Top Cover Hardware - New Style
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	914917	Plate - Stop	2	Includes a Nut.
2	852616	Washer	10	
3	852961	Washer - Lock	10	
4	619284	Screw	10	
5	914915	Spindle - Stop, Cushion	2	
6	246984	Washer	3	
7	943419	Pin - Hinge	3	
8	968795	Plate - Hinge	2	
9	852698	Screw	8	
10	943663	Bearing	3	
11	943686	Latch - Cover	1	
12	498941	Magnet - Actuator	1	
13	575822	Washer	4	
14	191098	Washer - Lock	4	
15	575821	Screw	1	
16	288235	Plate - Nut	1	
17	911689	Block - Hinge Plate	1	
18	556032	Screw - Detector	1	
19	914599	Switch - Detector	1	

Figure 2-4 Top Cover Hardware - New Style
Order by Part Number



H104 0106ECB
P104 0106EA

Figure 2-5 Top Cover Hardware - Old Style, Left Side
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	498941	Magnet - Actuator	1	
2	911730	Plate - Top Cover, Hinge.....	1	
3	914599	Switch - Detector	1	
4	288235	Plate - Nut.....	1	
5	914883	Pin - Hinge, Top Cover.....	1	
6	182399	Bearing.....	1	

Figure 2-5 Top Cover Hardware - Old Style, Left Side
Order by Part Number





Figure 2-6 Top Cover Hardware - Old Style, Right Side
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	542088	Catch Assembly	1	
2	542087	Rod Assembly	1	
3	852698	Screw	1	
4	911730	Plate - Top Cover, Hinge.....	1	
5	182399	Bearing	1	
6	914883	Pin - Hinge, Top Cover.....	1	

Figure 2-6 Top Cover Hardware - Old Style, Right Side
Order by Part Number



H104_0433DCA
H104_0433DA

Figure 2-7 Internal Covers
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	1C4393	Cover - Wet Section	1	
2	911707	Cover - Autotransformer	1	
3	911708	Cover - Splash	1	
4	613122	Cover - Evaporation.....	2	

Figure 2-7 Internal Covers
Order by Part Number


BLANK PAGE

SECTION 3

Roller Transport System

Table of Contents

Description	Page
Complete Rack and Crossover Assemblies	3-3
Detector Crossover	3-5
Detector Crossover - Drive Side	3-7
Detector Crossover - Non-Drive Side	3-9
Developer Rack Assembly	3-10
Developer Rack - Roller Assemblies	3-11
Developer Rack - Exit Rollers	3-13
Developer Rack - Other Rollers	3-15
Developer Rack - Master Rollers	3-17
Developer Rack - Guide Shoes	3-19
Developer/Fixer Crossover Assembly	3-21
Developer/Fixer Crossover - Drive Side	3-23
Developer/Fixer Crossover - Non-Drive Side	3-25
Fixer Rack Assembly	3-26
Fixer Rack - Roller Assemblies	3-27
Fixer Rack - Exit Rollers	3-29
Fixer Rack - Other Rollers	3-31
Fixer Rack - Master Rollers	3-33
Fixer Rack - Guide Shoes	3-35
Fixer/Wash Crossover Assembly	3-37
Fixer/Wash Crossover - Drive Side	3-39
Fixer/Wash Crossover - Non-Drive Side	3-41
Wash Rack Assembly - Mod 17 Not Installed	3-42
Wash Rack, Mod 17 Not Installed - Roller Assemblies	3-43
Wash Rack, Mod 17 Not Installed - Top Rollers	3-45
Wash Rack, Mod 17 Not Installed - Other Rollers	3-47
Wash Rack, Mod 17 Not Installed - Guide Shoes	3-49
Wash Rack Assembly - Mod 17 Installed	3-50
Wash Rack, Mod 17 Installed - Roller Assemblies	3-51
Wash Rack, Mod 17 Installed - Top Rollers	3-53
Wash Rack, Mod 17 Installed - Other Rollers	3-55
Wash Rack, Mod 17 Installed - Guide Shoes	3-57
Dryer Rack Assembly	3-58
Dryer Rack - Roller Assemblies	3-59
Dryer Rack - Air Tubes	3-61
Dryer Rack - Squeegee Rollers	3-63
Dryer Rack - Other Rollers, 1 of 2	3-65
Dryer Rack - Other Rollers, 2 of 2	3-67
Dryer Rack - Drive Chain Cover and Plenum	3-69
Top Exit Rack	3-71
Top Exit Rack With Mod 10 or Mod 13 Installed	3-73
Top Exit Rack With Mod 13 Installed	3-75
Top Exit Rack With Mod 10 Installed, Without Mod 13 Installed	3-77




H127_0129DCA
H104_0479DA

Figure 3-1 Complete Rack and Crossover Assemblies
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	918945	Crossover - Fixer/Wash	1	
2	779101	Rack - Wash	1	
3	696092	Rack - Exit, Top	1	
4	696093	Rack - Dryer.....	1	
5	918943	Crossover - Detector.....	1	
6	918938	Rack - Developer	1	
7	918944	Crossover - Developer/Fixer	1	
8	918939	Rack - Fixer	1	

Figure 3-1 Complete Rack and Crossover Assemblies
Order by Part Number




H127_0120DCA
H127_0120da

Figure 3-2 Detector Crossover
Order by Part Number

Item	Part No.	Description	Qty.	Notes
	918943	Crossover - Detector.....	1	Complete Crossover Assembly
1	490109	Roller - Detector.....	1	A
2	458170	Rod - Tie	1	
3	490108	Roller - Detector.....	1	B
4	458953	Guide Shoe	1	

Figure 3-2 Detector Crossover
Order by Part Number




H127_0121DCB
H127_0121DA

Figure 3-3 Detector Crossover - Drive Side
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	650707	Bearing	2	
2	472592	Rocker - Bearing	2	
3	489997	Standoff - Pivot	2	
4	474180	Support	2	
5	650876	Actuator - Magnet	2	
6	575822	Washer	2	
7	187283	Washer - Lock	2	
8	575821	Screw	2	
9	853087	Washer - Lock	2	
10	852682	Screw	2	
11	852611	Washer	2	
12	165627	Washer	2	
13	853096	Washer - Lock	2	
14	544194	Screw	2	
15	550781	Gear - Drive, Crossover	1	
16	502464	Pin	1	
17	651107	E-Ring	3	
18	779119	Bearing	2	
19	562228	Stud - Snap-In	2	
20	562330	Roller	1	
21	472756	Nut - Special D, Long	1	
22	594233	Bracket - Film Guide Shoe	2	
23	458953	Guide Shoe	1	
24	183322	Screw	4	
25	458170	Rod - Tie	1	
26	418775	Washer - Thrust	2	
27	594229	Shaft	1	
28	458175	Shaft	1	
29	779433	Side Plate - Detector Crossover, Drive Side	1	
30	490108	Roller - Detector	1	B
31	490109	Roller - Detector	1	A

Figure 3-3 Detector Crossover - Drive Side
Order by Part Number




H127_0122DCA
H127_0122DA

Figure 3-4 Detector Crossover - Non-Drive Side
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	458175	Shaft	1	C
2	594229	Shaft	1	
3	458170	Rod - Tie	1	
4	183322	Screw	4	
5	458953	Guide Shoe	1	
6	594233	Bracket - Film Guide Shoe	2	
7	472755	Nut - Special N-D, Short	1	
8	562330	Roller	1	
9	779434	Side Plate - Detector Crossover, Non-Drive Side	1	
10	562228	Stud - Snap-In	2	
11	779119	Bearing	2	
12	418775	Washer - Thrust	2	
13	651107	E-Ring	3	
14	544194	Screw	2	
15	853096	Washer - Lock	2	
16	165627	Washer	2	
17	489997	Standoff - Pivot	2	
18	852611	Washer	2	
19	853087	Washer - Lock	2	
20	852682	Screw	2	
21	575821	Screw	2	
22	187283	Washer - Lock	2	
23	575822	Washer	2	
24	650876	Actuator - Magnet	2	
25	474180	Support	2	
26	472592	Rocker - Bearing	2	
27	650707	Bearing	2	


Figure 3-4 Detector Crossover - Non-Drive Side
Order by Part Number



H127 0107DA

Item	Part No.	Description	Qty.	Notes
	918938	Rack - Developer	1	Complete Rack Assembly

Figure 3-5 Developer Rack Assembly
Order by Part Number



H127_0108CA

Item	Part No.	Description	Qty.	Notes
A	594237	Roller	1	
B	968796	Roller	1	
C	594271	Roller - Rewet	1	
D	911661	Roller	1	
E,F,G	1C7381	Roller	7	
H	594288	Roller	1	
J	594243	Roller	1	
K	748875	Roller	2	

Figure 3-6 Developer Rack - Roller Assemblies, Drive Side
Order by Part Number




Figure 3-7 Developer Rack - Exit Rollers
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	651107	E-Ring	7	A B
2	943473	Shaft	1	
3	594237	Roller	1	
4	968796	Roller	1	
5	594254	Gear	1	
6	852611	Washer		
7	853087	Washer - Lock.....	1	
8	853080	Nut.....	1	
9	502464	Pin	2	
10	550774	Gear	1	
11	594273	Bearing	2	C
12	467843	Spring	2	
13	779432	Side Plate - Developer, Drive Side.....	1	
14	594255	Bushing	1	
15	594297	Gear - Idler.....	1	
16	544132	Screw	1	
17	246981	Shaft	1	
18	594271	Roller - Rewet	1	
19	779431	Side Plate - Developer, Non-Drive Side.....	1	
20	779334	Chain - Roller	1	
21	594261	Sprocket	1	
22	418775	Washer - Thrust	1	
23	779119	Bearing	4	
24	562226	Washer	2	

Figure 3-7 Developer Rack - Exit Rollers
Order by Part Number





Figure 3-8 Developer Rack - Other Rollers
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	562228	Stud - Snap-In.....	18	D E, F, & G H
2	594248	Gear - Snap-In.....	9	
3	911661	Roller.....	1	
4	594251	Gear - Snap-In.....	1	
5	1C7381	Roller.....	7	
6	594288	Roller.....	1	
7	594291	Gear - Gudgeon, Compound.....	1	
8	779432	Side Plate - Developer, Drive Side.....	1	
9	779431	Side Plate - Developer, Non-Drive Side.....	1	

Figure 3-8 Developer Rack - Other Rollers
Order by Part Number




H127 0105ECA
H127 0105EA

Figure 3-9 Developer Rack - Master Rollers
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	779334	Chain - Roller.....	1	
2	853141	Screw	1	
3	852611	Washer	4	
4	594253	Idler - Chain	4	
5	594252	Sleeve	1	
6	853087	Washer - Lock.....	2	
7	853080	Nut.....	2	
8	594241	Gear	1	
9	594240	Bushing	1	
10	594320	Screw	1	
11	852807	Screw	1	
12	981894	Locator	1	
13	911692	Deflector - Rack	1	
14	779119	Bearing.....	6	
15	651107	E-Ring	9	
16	562500	Spring.....	2	
17	748875	Roller	2	K
18	594236	Shaft.....	1	
19	594243	Roller	1	J
20	594242	Shaft.....	1	
21	562226	Washer.....	1	
22	418775	Washer - Thrust	1	
23	613246	Sprocket	1	
24	502464	Pin	1	

Figure 3-9 Developer Rack - Master Rollers
Order by Part Number




H127_0106ECA
H127_0106EA

Figure 3-10 Developer Rack - Guide Shoes
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	458219	Rod - Tie	5	
2	562765	Guide Shoe	2	
3	183322	Screw	12	
4	474596	Bracket - Film Guide Shoe	6	
5	852807	Screw	10	
6	914703	Guide Shoe	1	
7	459943	Washer - I/D Developer	1	


Figure 3-10 Developer Rack - Guide Shoes
Order by Part Number



H127_0123DCA
H127_0123da

Figure 3-11 Developer/Fixer Crossover Assembly
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	918944	Crossover - Developer/Fixer	1	Assembly includes Trough 914920.
	914920	Trough - Crossover, Developer/Fixer	1	




H127_0127DCA
H127_0124da

Figure 3-12 Developer/Fixer Crossover - Drive Side
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	183322	Screw	4	
2	474596	Bracket - Film Guide Shoe	1	
3	779435	Side Plate - Crossover.....	1	
4	472756	Nut - Special D, Long	1	
5	1C7106	Spring - Extension	1	
6	550781	Gear - Drive, Crossover.....	1	
7	502464	Pin	1	
8	651107	E-Ring	2	
9	779119	Bearing	2	
10	459946	Washer - I/D.....	1	
11	418775	Washer - Thrust	1	
12	594233	Bracket - Film Guide Shoe	1	
13	458953	Guide Shoe	1	
14	594229	Shaft	1	
15	594230	Shaft	1	
16	458170	Rod - Tie	1	
17	562389	Guide Shoe	1	


Figure 3-12 Developer/Fixer Crossover - Drive Side
Order by Part Number



2B6844: 5/94

Item	Part No.	Description	Qty.	Notes
1	183322	Screw	4	A & B
2	562389	Guide Shoe	1	
3	458170	Rod - Tie	1	
4	594230	Shaft	1	
5	594237	Roller	2	
6	594229	Shaft	1	
7	458953	Guide Shoe	1	
8	594233	Bracket - Film Guide Shoe	1	
9	779435	Side Plate - Crossover.....	1	
10	779119	Bearing.....	2	
11	418775	Washer - Thrust	1	
12	651107	E-Ring	2	
13	1C7106	Spring - Extension	1	
14	472755	Nut - Special N-D, Short.....	1	
15	474596	Bracket - Film Guide Shoe	1	


Figure 3-13 Developer/Fixer Crossover - Non-Drive Side
Order by Part Number



H127 0114da

Item	Part No.	Description	Qty.	Notes
	918939	Rack - Fixer	1	Complete Rack Assembly

Figure 3-14 Fixer Rack Assembly
Order by Part Number



H127_0113CA

Item	Part No.	Description	Qty.	Notes
A	594237	Roller	1	
B	246979	Roller	1	
C	594271	Roller - Rewet	1	
D	943441	Roller	1	
E,F,G	1C7381	Roller	5	
H	594288	Roller	1	
J	594244	Roller	1	
K	748875	Roller	2	
L	594237	Roller	1	

Figure 3-15 Fixer Rack - Roller Assemblies
Order by Part Number





Figure 3-16 Fixer Rack - Exit Rollers
Order by Part Number




H127_0110ECA
H104_0428EA

Figure 3-17 Fixer Rack - Other Rollers
Order by Part Number


Item	Part No.	Description	Qty.	Notes
1	502464	Pin	1	D E, F, & G L H
2	911663	Gear	1	
3	943468	Shaft	2	
4	594248	Gear - Snap-In	7	
5	943441	Roller	1	
6	1C7381	Roller	6	
7	594237	Roller	1	
8	594254	Gear	1	
9	779119	Bearing	4	
10	1C7106	Spring - Extension	2	
11	651107	E-Ring	7	
12	562228	Stud - Snap-In	14	
13	594288	Roller	1	
14	594291	Gear - Gudgeon, Compound	1	

Figure 3-17 Fixer Rack - Other Rollers
Order by Part Number



H127_0111ECA
H127_0111ea

Figure 3-18 Fixer Rack - Master Rollers
Order by Part Number




H127_0112ECA
H127_0112ea

Figure 3-19 Fixer Rack - Guide Shoes
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	458219	Rod - Tie	5	
2	474596	Bracket - Film Guide Shoe	6	
3	562765	Guide Shoe	2	
4	183322	Screw	12	
5	914703	Guide Shoe	1	
6	852807	Screw	10	
7	459944	Washer - I/D.....	1	

Figure 3-19 Fixer Rack - Guide Shoes
Order by Part Number




H127_0126DCA
H127_0126da

Figure 3-20 Fixer/Wash Crossover Assembly
Order by Part Number

Item	Part No.	Description	Qty.	Notes
	918945	Crossover - Fixer/Wash	1	Assembly includes Trough 914922.
1	914922	Trough - Crossover, Fixer/Wash	1	

Figure 3-20 Fixer/Wash Crossover Assembly
Order by Part Number




H127_0127DCA
H127_0127da

Figure 3-21 Fixer/Wash Crossover - Drive Side
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	183322	Screw	4	
2	474596	Bracket - Film Guide Shoe	1	
3	779435	Side Plate - Crossover.....	1	
4	472756	Nut - Special D, Long	1	
5	1C7106	Spring - Extension	1	
6	550781	Gear - Drive, Crossover.....	1	
7	502464	Pin	1	
8	651107	E-Ring	2	
9	779119	Bearing.....	2	
10	459947	Washer - I/D.....	1	
11	418775	Washer - Thrust.....	1	
12	594233	Bracket - Film Guide Shoe	1	
13	914701	Guide Shoe	1	
14	594229	Shaft	1	
15	594230	Shaft.....	1	
16	458170	Rod - Tie	1	
17	562389	Guide Shoe	1	

Figure 3-21 Fixer/Wash Crossover - Drive Side
Order by Part Number




H127_0128DCC
H127_0128DA

Figure 3-22 Fixer/Wash Crossover - Non-Drive Side
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	183322	Screw	4	B
2	562389	Guide Shoe	1	
3	458170	Rod - Tie	1	
4	594230	Shaft	1	
5	594237	Roller	1	
6	594229	Shaft	1	
7	914701	Guide Shoe	1	
8	594233	Bracket - Film Guide Shoe	1	
9	779435	Side Plate - Crossover.....	1	
10	779119	Bearing	2	
11	418775	Washer - Thrust	1	
12	651107	E-Ring	2	
13	1C7106	Spring - Extension	1	
14	472755	Nut - Special N-D, Short.....	1	
15	474596	Bracket - Film Guide Shoe	1	
16	911660	Roller	1	A


Figure 3-22 Fixer/Wash Crossover - Non-Drive Side
Order by Part Number



H127_0118DCA
H127_0118da

Item	Part No.	Description	Qty.	Notes
		Rack - Wash	1	Complete Rack Assembly, prior to Mod 17. No longer available. See page 3-50.
1	779349	Guard - Splash.....	1	


Figure 3-23 Wash Rack Assembly - Mod 17 Not Installed
Order by Part Number



H127_0119CA

Item	Part No.	Description	Qty.	Notes
A	911651	Shaft	1	For early processors, see the Service Manual 2B6854, page 2-5.
B,C	911660	Roller	3	
D	246979	Roller	3	

Figure 3-24 Wash Rack, Mod 17 Not Installed - Roller Assemblies
Order by Part Number




H127_0115ECA
H127_0115EA

Figure 3-25 Wash Rack, Mod 17 Not Installed - Top Rollers
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	911651	Shaft	1	A. D. For early processors, see the Service Manual 2B6854, page 2-5. B.
2	990019	Shaft	1	
3	246982	Shaft	1	
4	246979	Roller	1	
5	911660	Roller	1	
6	502464	Pin	4	
7	779028	Gear	4	
8	779345	Side Plate - Wash, Drive Side	1	
9	550781	Gear - Drive, Crossover	1	
10	1C7107	Spring - Extension	2	
11	1C4392	Side Plate - Wash, Non-Drive Side	1	
12	911725	Bushing - Idle	1	
13	911724	Screw - Shoulder	1	
14	651107	E-Ring	10	
15	418775	Washer - Thrust	2	
16	779119	Bearing	6	

Figure 3-25 Wash Rack, Mod 17 Not Installed - Top Rollers
Order by Part Number




H127_0116ECB
H127_0116EA

Figure 3-26 Wash Rack, Mod 17 Not Installed - Other Rollers
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	651107	E-Ring	10	C.
2	246982	Shaft	2	
3	911660	Roller	2	
4	779345	Side Plate - Wash, Drive Side.....	1	
5	1C7107	Spring - Extension	4	
6	911725	Bushing - Idle.....	1	
7	911724	Screw - Shoulder	1	
8	779028	Gear	3	
9	779070	Side Plate - Wash, Non-Drive Side	1	
10	990019	Shaft	2	
11	246979	Roller	2	
				D. For early processors, see the Service Manual 2B6854, page 2-5.
12	502464	Pin	2	
13	418775	Washer - Thrust	1	

Figure 3-26 Wash Rack, Mod 17 Not Installed - Other Rollers
Order by Part Number




H127_0117ECA
H127_0117EA

Figure 3-27 Wash Rack, Mod 17 Not Installed - Guide Shoes
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	458219	Rod - Tie	3	
2	779348	Inlet - Bar, Spray	1	
3	779347	Bar - Spray	2	
4	453342	O-Ring	4	
5	779466	Tubing - Formed	1	
6	779355	Mount - Bar, Spray	1	
7	1C7399	Yoke and Pin Assembly	1	
8	914745	Clip - Stand-off	1	
9	852682	Screw	8	
10	183322	Screw	4	
11	474596	Bracket - Film Guide Shoe	2	
12	914703	Guide Shoe	1	
13	943700	Coupling - Insert	1	
14	968740	Tubing - Formed	1	
15	182590	Tie	1	Not Shown


Figure 3-27 Wash Rack, Mod 17 Not Installed - Guide Shoes
Order by Part Number



H127_0171EA

Item	Part No.	Description	Qty.	Notes
	1C4962	Rack - Wash	1	Complete Rack Assembly.


Figure 3-28 Wash Rack Assembly - Mod 17 Installed
Order by Part Number



H127_0119CA

Item	Part No.	Description	Qty.	Notes
A	911651	Shaft	1	For early processors, see the Service Manual 2B6854, page 2-5.
B,C	911660	Roller	3	
D	246979	Roller	3	

Figure 3-29 Wash Rack, Mod 17 Installed - Roller Assemblies
Order by Part Number




H127 0115ECA
H127 0115EA

Figure 3-30 Wash Rack, Mod 17 Installed - Top Rollers
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	911651	Shaft	1	A. D. For early processors, see the Service Manual 2B6854, page 2-5. B.
2	990019	Shaft	1	
3	246982	Shaft	1	
4	246979	Roller	1	
5	911660	Roller	1	
6	502464	Pin	4	
7	779028	Gear	4	
8	779345	Side Plate - Wash, Drive Side.....	1	
9	550781	Gear - Drive, Crossover.....	1	
10	1C7107	Spring - Extension	2	
11	1C4392	Side Plate - Wash, Non-Drive Side.....	1	
12	911725	Bushing - Idle.....	1	
13	911724	Screw - Shoulder	1	
14	651107	E-Ring	10	
15	418775	Washer - Thrust	2	
16	779119	Bearing.....	6	

Figure 3-30 Wash Rack, Mod 17 Installed - Top Rollers
Order by Part Number



H127 0116ECB
H127 0116EA

Figure 3-31 Wash Rack, Mod 17 Installed - Other Rollers
Order by Part Number

2B6844: 5/94

Item	Part No.	Description	Qty.	Notes
1	651107	E-Ring	10	C.
2	246982	Shaft	2	
3	911660	Roller	2	
4	779345	Side Plate - Wash, Drive Side	1	
5	1C7107	Spring - Extension	4	
6	911725	Bushing - Idle	1	
7	911724	Screw - Shoulder	1	
8	779028	Gear	3	
9	1C4392	Side Plate - Wash, Non-Drive Side	1	
10	990019	Shaft	2	
11	246979	Roller	2	
				D. For early processors, see the Service Manual 2B6854, page 2-5.
12	502464	Pin	2	
13	418775	Washer - Thrust	1	

Figure 3-31 Wash Rack, Mod 17 Installed - Other Rollers
Order by Part Number





Figure 3-32 Wash Rack, Mod 17 Installed - Guide Shoes
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	1C4398	Assembly - Tubing	1	
2	852682	Screw	7	
3	1C0998	Bracket - Tubing	1	
4	1C4391	Manifold - Water	1	
5	458219	Rod - Tie	3	
6	1C4384	Tube - Yoke Supply	1	
7	1C4385	Hose - Yoke	1	
8	1C7399	Yoke and Pin Assembly.....	1	
9	914745	Clip - Stand-off.....	1	
10	183322	Screw	4	
11	474596	Bracket - Film Guide Shoe	2	
12	914703	Guide Shoe	1	
13	852522	Screw	2	


Figure 3-32 Wash Rack, Mod 17 Installed - Guide Shoes
Order by Part Number



H104_0396DA

Item	Part No.	Description	Qty.	Notes
	696093	Rack - Dryer.....	1	Mod 13, 968734, must be installed to use this rack.

Figure 3-33 Dryer Rack Assembly
Order by Part Number



H127_0089ECA
H104_0397EA

Figure 3-35 Dryer Rack - Air Tubes
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	532164	Bar - Tie	6	S
2	240101	Air Tube - Metal	5	
3	534770	Deflector - Air Tube	5	
4	562609	Spring - Air Tube	10	
5	914875	Bracket - Captive	2	
6	852811	Screw	2	B
7	474596	Bracket - Film Guide Shoe	2	
8	914921	Air Tube - Snouted, Black	5	
9	914704	Guide Shoe	1	
10	183322	Screw	4	

Figure 3-35 Dryer Rack - Air Tubes
Order by Part Number




Figure 3-36 Dryer Rack - Squeegee Rollers
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	968736	Shaft	1	D. Includes items 17 and 18, 619512 (2) and 3B7301 (1). K. J.
2	544081	Pin	2	
3	544070	Gear	2	
4	911660	Roller	1	
5	1C4952	Shaft - Drive	1	
6	651107	E-Ring	12	
7	779119	Bearing	8	
8	914736	Sprocket	4	
9	502464	Pin	5	
10	914737	Chain	1	
11	550774	Gear	1	
12	914738	Chain	1	
13	246580	Spring	2	
14	418775	Washer - Thrust	1	
15	1C0985	Roller - Squeegee, Driven	1	
16	1C0983	Roller - Squeegee, Drive	1	
17	619512	Washer - Thrust	2	
18	3B7301	Bearing - Thrust	1	
19	911664	Gear	1	

Figure 3-36 Dryer Rack - Squeegee Rollers
Order by Part Number




Figure 3-37 Dryer Rack - Other Rollers, 1 of 2
Order by Part Number

2B6844: 5/94

Item	Part No.	Description	Qty.	Notes
1	911660	Roller	1	F
2	651107	E-Ring	5	
3	911663	Gear	1	
4	502464	Pin	3	
5	990010	Screw - Shoulder	5	
6	418775	Washer - Thrust	3	
7	911663	Gear	1	
8	779119	Bearing	4	
9	911664	Gear	2	
10	562228	Stud - Snap-In	2	
11	911662	Roller	1	H G
12	911660	Roller	1	
13	748021	Shaft	2	
14	990003	Side Plate - Non-Drive Side	1	
15	990002	Side Plate - Drive Side	1	

Figure 3-37 Dryer Rack - Other Rollers, 1 of 2
Order by Part Number





Figure 3-38 Dryer Rack - Other Rollers, 2 of 2
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	911664	Gear	1	M
2	651107	E-Ring	4	
3	748022	Shaft	1	
4	911660	Roller	1	
5	779119	Bearing	2	
6	562228	Stud - Snap-In	14	C & E
7	594248	Gear - Snap-In	1	
8	587329	Roller	7	
9	532124	Gear - Snap-In	7	
10	502464	Pin	1	
11	943469	Gudgeon - Snap-In	6	

Figure 3-38 Dryer Rack - Other Rollers, 2 of 2
Order by Part Number




H104_0398DCA
H104_0398DA

Figure 3-39 Dryer Rack - Drive Chain Cover and Plenum
Order by Part Number

2B6844: 5/94

Item	Part No.	Description	Qty.	Notes
1	955595	Bracket - Stop, Non-Drive.....	1	
2	575821	Screw	2	
3	852945	Screw	4	
4	943662	Plenum - Dryer.....	1	
5	914712	Cover - Dryer, Front.....	1	
6	918931	Cover - Chain, Drive	1	
7	852811	Screw	1	
8	955596	Bracket - Stop, Drive	1	
9	852616	Washer	2	
10	852945	Screw	1	

Figure 3-39 Dryer Rack - Drive Chain Cover and Plenum
Order by Part Number



H104_0468DCA
H104_0468DA

Figure 3-40 Top Exit Rack
Order by Part Number

2B6844: 5/94

Item	Part No.	Description	Qty.	Notes
	696092	Rack - Exit, Top	1	Mod 13, 968734, must be installed to use this rack assembly.
1	914742	Cover - Top Exit Rack	1	Top Exit Rack includes Top Exit Rack Cover 914742.

Figure 3-40 Top Exit Rack
Order by Part Number





Figure 3-41 Top Exit Rack With Mod 10
or Mod 13 Installed
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	183322	Screw	8	
2	474596	Bracket - Film Guide Shoe	4	
3	458394	Rod - Tie	1	
4	911682	Rod - Tie	1	
5	911683	Nut - Special	2	
6	852682	Screw	2	
7	911749	Guide Shoe	1	
8	911748	Guide Shoe	1	

Figure 3-41 Top Exit Rack With Mod 10
or Mod 13 Installed
Order by Part Number



H104_0395ECA
H104_0395EA

Figure 3-42 Top Exit Rack With Mod 13 Installed
Order by Part Number

2B6844: 5/94

Item	Part No.	Description	Qty.	Notes
1	943441	Roller	1	A
2	594237	Roller	1	B
3	990010	Screw - Shoulder	2	
4	990327	Gear	2	
5	418775	Washer - Thrust	2	
6	911684	Bearing	12	
7	651107	E-Ring	12	
8	696090	Side Plate - Drive Side	1	
9	1C7106	Spring - Extension	4	
10	911660	Roller	1	E
11	246979	Roller	1	F
12	990014	Roller	1	C
13	990015	Roller	1	D
14	911653	Shaft	6	
15	696091	Side Plate - Non-Drive Side	1	

Figure 3-42 Top Exit Rack With Mod 13 Installed
Order by Part Number





Figure 3-43 Top Exit Rack With Mod 10 Installed, Without Mod 13 Installed
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	943441	Roller	1	A
2	594237	Roller	1	B
3	911691	Screw - Shoulder	2	
4	562615	Gear - 20-Tooth	2	
5	1C7106	Spring - Extension	4	
6	911660	Roller	2	C
7	246979	Roller	2	D
8	911653	Shaft	6	

Figure 3-43 Top Exit Rack With Mod 10 Installed, Without Mod 13 Installed

BLANK PAGE

SECTION 4
Main Drive Assembly




H104_0053ECB
P104_0053EA

Figure 4-1 Main Drive Shaft
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	748956	Gear - Worm, Right-hand	3	Quantity will vary.
2	853000	Pin	7	
3	748955	Gear - Worm, Left-hand.....	4	
4	911656	Shaft - Drive.....	1	
5	619284	Screw	10	
6	852961	Washer - Lock.....	12	
7	852616	Washer	12	
8	192904	E-Ring	1	
9	911732	Shim	2	
10	562650	Shield	2	
11	595426	Bearing.....	2	
12	594103	Retainer - Bearing.....	2	
13	748957	Washer.....	3	
14	897205	Bearing - Thrust	1	
15	914721	Sprocket - Drive	1	
16	911727	Chain - Drive	1	
17	187235	Screw	2	
18	990021	Mount - Bearing, Dryer End.....	1	
19	914898	Pin - Dowel	1	
20	911731	Mount - Bearing, Feed End	1	

Figure 4-1 Main Drive Shaft
Order by Part Number



H104_0412HCA
H104_0412HA


Figure 4-2 Main Drive Motor
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	779325	Gear Box	1	
2	914547	Motor	1	
3	914518	Screw	3	
4	852616	Washer	11	
5	852961	Washer - Lock	6	
6	852800	Nut	4	
7	454454	Sprocket - Drive	1	
8	619284	Screw	3	
9	852961	Washer - Lock	3	
10	779389	Cover - Drive Chain Guard	1	
11	911727	Chain - Drive	1	
12	852558	Setscrew	1	

Figure 4-2 Main Drive Motor
Order by Part Number

BLANK PAGE

SECTION 5
Dryer Assembly



H104_0413ECA
H104_0413EA

Figure 5-1 Dryer Assembly
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	911675	Plenum - Air Return	1	
2	911735	Bracket - Plenum	2	
3	852616	Washer	8	
4	852961	Washer - Lock.....	8	
5	619284	Screw	8	
6	531927	Clamp	2	
7	852611	Washer	4	
8	191098	Washer - Lock.....	5	
9	556032	Screw - Detector	2	
10	911678	Adapter - Plenum End	1	
11	911676	Hose	1	
12	902351	Fitting.....	1	
13	911674	Adaptor - Exhaust	1	
14	165627	Washer	1	
15	187213	Washer - Lock.....	1	
16	852522	Screw	1	
17	748638	Blower Assembly - Dryer.....	1	
18	532108	Sleeve - Blower, Outlet.....	1	
19	914706	Cover - Plenum Assembly	1	
20	918383	Label - Caution	1	
21	852682	Screw	5	
22	853100	Washer - Lock.....	5	
23	914723	Plate	1	
24	748511	Heater - Dryer	1	
25	914744	Screen - Heater	1	
26	556032	Screw - Detector	2	
27	943400	Bracket - Switch.....	1	
28	943375	Switch - Dryer, Airflow	1	


Figure 5-1 Dryer Assembly
Order by Part Number

BLANK PAGE

SECTION 6
Plumbing

Table of Contents


Description	Page
Heat Exchanger	6-3
Solution Thermowell	6-5
Recirculation Pump Assembly	6-7
Replenishment Pump Assembly	6-9
Mandrel Filter Assembly	6-11
Bulkhead Fittings	6-13
Developer Plumbing Diagram	6-15
Fixer Plumbing Diagram	6-17
Wash Plumbing Diagram	6-19



H127_0020DCA
P127_0020DA

Item	Part No.	Description	Qty.	Notes
1	914724	Exchanger - Heat.....	1	
2	532378	O-Ring.....	1	
3	532379	Washer.....	1	
4	990418	Plug - Gland Sealing.....	1	

Figure 6-1 Heat Exchanger
Order by Part Number




P104_0020DCA
P104_0020DA

Figure 6-2 Solution Thermowell
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	541891	Plug - Thermowell.....	1	
2	607793	Locator	1	
3	911432	Thermistor - Solution	1	
4	478510	Fitting - Elbow	1	
5	607748	Thermowell.....	1	
6	696165	Heater - Solution.....	1	

Figure 6-2 Solution Thermowell
Order by Part Number




H104_0033DCB
P104_0033DA

Figure 6-3 Recirculation Pump Assembly
Order by Part Number

Item	Part No.	Description	Qty.	Notes
	779342	Recirculation Pump Assembly	1	Includes all the items on this page.
1	472605	Housing - Left Side	1	
2	473926	Magnet	2	
3	418700	Housing - Inner	2	
4	474362	Impeller.....	2	
5	493505	Washer.....	2	
6	852946	Screw	2	
7	463363	O-Ring	2	
8	472606	Housing - Right Side.....	1	
9	144097	Nut - Wing.....	8	
10	418701	Housing and Impeller Assembly	2	Includes items 3 - 6.

Figure 6-3 Recirculation Pump Assembly
Order by Part Number




H104 0038ECB
P104 0038EA

Figure 6-4 Replenishment Pump Assembly
Order by Part Number

2B6844: 5/94

Item	Part No.	Description	Qty.	Notes
	955736	Replenishment Pump Assembly	1	Includes all the items on this page.
1	520390	Fitting - Elbow	2	
2	520391	Nut	2	
3	520388	O-Ring	2	
4	609817	Valve - Poppet	2	
5	535638	Body - Valve	1	
6	535639	O-Ring	2	
7	532008	Bellows	1	
8	594838	Cup - Displacement	1	
9	520391	Nut	1	

Figure 6-4 Replenishment Pump Assembly
Order by Part Number



H127_0096ECA
H127_0096ea

Figure 6-5 Mandrel Filter Assembly
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	914719	Mandrel - Fixer, Blue	1	Includes items 3 and 4.
	779330	Mandrel - Developer, Red	1	Includes items 3 and 4.
2	943442	Filter - Cartridge, Developer	1	
3	740639	Nut - Wing.....	1	
4	740721	O-Ring	1	

Figure 6-5 Mandrel Filter Assembly
Order by Part Number





Figure 6-6 Bulkhead Fittings
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	779376	Nut - Jam, 3/8 - 20	2	Fixer.
2	779377	Nut - Jam, 5/8 - 16	4	
3	779378	Nut - Jam, 1-inch - 12.....	3	
4	779359	Valve - Drain, Blue.....	1	
5	499754	Connector - Hose.....	2	
6	1C4523	Fitting - Bulkhead, 1-inch.....	1	Includes Rubber Washer 1C4721. Developer. Includes Rubber Washer 489174.
7	1C4721	Washer - Rubber, 5/8-inch	2	
8	1C4519	Fitting - Bulkhead, 5/8-inch.....	4	
9	779468	Valve - Drain, Red	1	
10	1C4520	Fitting - Bulkhead, 3/8-inch.....	2	
11	489174	Washer - Rubber, 3/8-inch	2	
12	779358	Panel - Bulkhead	1	

Figure 6-6 Bulkhead Fittings
Order by Part Number




H104 0417EAA
H104 0417EA

Figure 6-7 Developer Plumbing Diagram
Order by Part Number

2B6844: 5/94

Item	Part No.	Description	Qty.	Notes
1	333951	Tubing - Formed	1	
2c	246808	Clamp - Hose	3	
3	779363	Tubing - Formed	1	
4	779382	Tubing - Formed	1	
5	180281	Fitting - T	1	
6c	246801	Clamp - Hose	8	
7	486480	Fitting - Elbow	2	
8	779344	Solenoid - Cooling	1	
9	779385	Tubing - Straight	1	
10	914732	Orifice .125 inches	1	
11	779384	Tubing - Formed	1	
12	477011	Fitting - Y	1	
13	779383	Tubing - Formed	1	
14	914731	Orifice .250 inches	1	
15	779388	Tubing - Formed	1	
16	779370	Tubing - Straight	1	
17c	246800	Clamp - Hose	4	
18	779364	Tubing - Formed	1	
19	779387	Tubing - Formed	1	
20	779366	Tubing - Formed	1	
21c	246803	Clamp - Hose	1	
22c	914908	Clamp - Hose	1	
23	779376	Nut - Jam, 3/8 - 20	1	
24	779373	Fitting - Bulkhead, 3/8 inch	1	
25	779368	Tubing - Formed	1	

Figure 6-7 Developer Plumbing Diagram
Order by Part Number




H104_0416EAA
H104_0416EA

Figure 6-8 Fixer Plumbing Diagram
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1c	246808	Clamp - Hose	5	
2	333951	Tubing - Formed	1	
3	459576	Orifice	1	
4c	246801	Clamp - Hose	3	
5	779363	Tubing - Formed	1	
6	779388	Tubing - Formed	1	
7	779660	Tubing - Formed	1	
8	779365	Tubing - Formed	1	
9c	246800	Clamp - Hose	4	
10c	914908	Clamp - Hose	1	
11	779366	Tubing - Formed	1	
12c	246803	Clamp - Hose	2	
13	779464	Tubing - Straight	1	
14	779368	Tubing - Formed	1	
15	779373	Fitting - Bulkhead, 3/8 inch.....	1	
16	779376	Nut - Jam, 3/8 - 20	1	

Figure 6-8 Fixer Plumbing Diagram
Order by Part Number



H104_0415EAA
H104_0415EA

Figure 6-9 Wash Plumbing Diagram
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	943701	Disconnect - Water	1	For Processors without Mod 17 installed. Includes Fittings. For Processors with Mod 17 installed. Includes Fittings.
2	594534	Washer	1	
3	594535	Gasket	1	
4c	914908	Clamp - Hose	1	
5c	246805	Clamp - Hose	1	
6c	246800	Clamp - Hose	4	
7	943665	Tubing - Straight	1	
8	779362	Tubing - Formed	1	
9	963541	Valve - Dole, 1 gal/min	1	
	1C4968	Valve - Dole, $\frac{3}{4}$ gal/min	1	
10	943668	Tubing Formed.....	1	
11c	246804	Clamp - Hose	1	
12c	246803	Clamp - Hose	1	
13	943666	Valve - Water Solenoid.....	1	
14	779365	Tubing - Formed	1	


Figure 6-9 Wash Plumbing Diagram
Order by Part Number

BLANK PAGE

SECTION 7
Electrical

Table of Contents

Description	Page
Detector Switches	7-3
Electrical Box	7-5
Interface Panel and Receptacle Panel	7-7
Microprocessor Board	7-9
Display Board Assembly	7-11
Dryer Over-Temperature Thermostat	7-13
Miscellaneous Electrical Parts Panel	7-15




H104_0430ECA
H104_0430EA

Figure 7-1 Detector Switches
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	852522	Screw	11	For earlier Processors, see the Service Manual 2B6845.
2	187213	Washer - Lock.....	11	
3	165627	Washer	11	
4	943445	Shield - Film Detector	1	
5	779333	Housing - Film Detector	1	
6	981893	Bracket - Detector Switch, Drive Side	1	
7	288235	Plate - Nut.....	2	
8	914599	Switch - Detector	2	
9	575822	Washer	4	
10	191098	Washer - Lock.....	4	
11	556032	Screw - Detector	4	
12	475493	Block - Hinge	2	
13	852982	Screw	2	
14	1C4042	Guard - Splash.....	1	
15	981892	Bracket - Detector Switch, Non-Drive Side	1	
16	610000	Standoff	3	Includes 475493 (2), item 12. For earlier Processors, see the Service Manual 2B6845.
17	990029	PROM - U12	1	
18	696156	Board - Univeral Film Detector, 5600.....	1	

Figure 7-1 Detector Switches
Order by Part Number




H104 0443ECA
H104 0443EA

Figure 7-2 Electrical Box
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	273691	Fuse - F1, 2.5 Amp.....	1	Order and install a new Varistor (item 35) whenever you install a new Solid State Relay.
2	597341	Fuse - F2, 8 Amp.....	1	
3	498607	Holder - Fuse.....	3	
	477506	Cap - Fuse Holder.....	3	
4	779406	Fuse - F5, 0.15 Amp.....	1	
5	264407	Fuse - F3 and F4, 2 Amp.....	2	
6	264405	Holder - Fuse, Buss.....	2	
7	911412	Controller - Motor.....	1	
8	903739	Shield - Ferrite.....	2	
9	914728	Ring - Pull.....	1	
10	981759	Board - Microprocessor, 500.....	1	
11	292888	Jack - ESD, Ground.....	1	
12	779438	Quencharc.....	2	
13	335500	Connector - J502.....	1	
14	914888	Fan.....	1	
15	943429	Cover - Power Supply.....	1	
16	165678	Screw.....	2	
17	187213	Washer - Lock.....	2	
18	165627	Washer.....	2	
19	241883	Block - Terminal.....	1	
20	955745	Power Supply - DC, Quad.....	1	
21	968748	Board - 600.....	1	
22	655290	Relay - Solid State.....	5	
23	943435	Coil.....	2	
24	785462	Coil.....	1	
25	918929	Spacer.....	2	
26	943427	Cover - Relay.....	1	
27	535039	Screw.....	2	
28	853100	Washer - Lock.....	2	
29	852611	Washer.....	2	
30	943444	Guard - Transformer.....	1	
31	243572	Block - Terminal.....	1	
32	779409	Transformer - 16 VAC.....	1	
33	748131	Relay - K1.....	1	
34	139941	Fuse - A1 F1, 5 Amp, 250 volts.....	1	
35	943378	Varistor - Metal Oxide.....	5	

Figure 7-2 Electrical Box
Order by Part Number




H104_0110DCB
P104_0110DA

Figure 7-3 Interface Panel and Receptacle Panel
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	918343	Breaker - Circuit, 20 Amps	1	Includes Switch Harness.
2	180271	Screw	6	
3	209234	Screw	2	
4	914899	Panel - Control Interface.....	1	Includes a Nut.
5	728326	Screw - Jack	1	
6	781405	Receptacle - Safelight.....	1	
7	748512	Jack - Interface, Phone.....	1	
8	943676	Panel - Safelight	1	
9	779732	Board - Control Interface, 200	1	
10	852774	Screw	2	

Figure 7-3 Interface Panel and Receptacle Panel
Order by Part Number




H104_0422DCA
H104_0422DA

Figure 7-4 Microprocessor Board
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	981759	Board - Microprocessor, 500	1	Includes CPU. Does not include U17, U18, U19, U20, or Battery.
2	227322	Battery	1	
3	990035	EEPROM Set - Main/Language Japanese.....	1	Includes U17, U18, & U19.
	990032	EEPROM Set - Main/Language Other Languages	1	
4	699551	PROM - Bootstrap	1	Includes U17, U18, & U19.

Figure 7-4 Microprocessor Board
Order by Part Number




H104_0420ECA
H104_0420EA

Figure 7-5 Display Board Assembly
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	914888	Fan	1	Includes Soft Keys.
2	955598	Mask - Display	1	
3	852774	Screw	4	
4	911414	Display.....	1	Does not include Display, item 4.
5	696159	Board - Display, 300	1	
6	852522	Screw	4	
7	779397	Panel - Safelight	1	
8	914912	Screw	10	
9	779458	Housing - Level Sensor, Developer.....	1	
10	918094	Button - Replenishment Switch Assembly.....	1	
11	779473	Housing - Level Sensor, Fixer	1	
12	779459	Probe - Level Sensor.....	2	
13	779454	Cover - Cable.....	1	
14	852802	Screw	6	
15	748043	Washer - Sealing	2	
16	575820	Screw	2	
17	544194	Screw	2	
18	955719	Switch - Replenishment Calibrate	1	
19	575822	Washer	1	
20	191098	Washer - Lock.....	4	
21	556032	Screw - Detector	4	
22	914599	Switch - Detector	1	
23	575821	Screw	2	
24	498941	Magnet - Actuator	1	
25	288235	Plate - Nut.....	1	
26	619284	Screw	8	

Figure 7-5 Display Board Assembly
Order by Part Number




H104_0414ECA
H104_0414EA

Figure 7-6 Dryer Over-Temperature Thermostat
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	914722	Bracket - Dryer Thermistor	1	
2	748024	Bracket - Over-Temperature Thermostat	1	
3	955741	Thermostat - Dryer, Over-Temperature	1	
4	575822	Washer	2	
5	191098	Washer - Lock.....	2	
6	191097	Screw	2	
7	911433	Thermistor - Dryer.....	1	
8	480820	Screw	1	
9	853100	Washer - Lock.....	1	
10	852611	Washer	1	
11	748023	Bracket - Dryer Thermistor/Thermostat	1	

Figure 7-6 Dryer Over-Temperature Thermostat
Order by Part Number



H104_0429DCA
H104_0429DA

Figure 7-7 Miscellaneous Electrical Parts
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	173865	Nut - Lock, 3/4-in.	1	
2	483051	Washer	2	
3	594782	Connector - Panel	1	
4	914596	Filter - EMI	1	
5	852611	Washer	4	
6	852523	Screw	2	
7	779428	Block - Terminal	1	
8	852871	Screw	2	
9	619284	Screw	2	
10	852961	Washer - Lock	2	
11	852616	Washer	2	
12	168424	Washer - Lock	2	
13	748501	Autotransformer	1	
14	779400	Strip - Terminal, TB2 and TB3	2	
15	851269	Washer - Star	4	
16	943903	Strip - Marker	2	
17	779401	Insulator	2	
18	852809	Screw	4	


Figure 7-7 Miscellaneous Electrical Parts
Order by Part Number

BLANK PAGE

SECTION 8
Miscellaneous

Table of Contents

Description	Page
Leveling Feet	8-3
Accessories	8-5
Miscellaneous Tank Assembly	8-7
Electrical Box Slides	8-9



P104_0131BCA
P104_0131BA

Item	Part No.	Description	Qty.	Notes
1	459229	Screw - Leveling	4	Not Shown
2	459548	Plate - Floor	4	
3	914895	Seismic Bracket Kit for processors with a stand.....	1	
4	914894	Seismic Bracket Kit for processors without a stand	1	

Figure 8-1 Leveling Feet
Order by Part Number




Figure 8-2 Accessories
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	459432	Tray - Drip.....	1	Not Shown
2	472261	Strainer Assembly.....	2	
3	479821	Graduate - Cylinder	1	
4	650938	Gasket - Lighttight, 10 ft roll	1	
5	918947	Guard - Splash.....	1	
	452990	Tubing - Replenishment.....	1	

Figure 8-2 Accessories
Order by Part Number





Figure 8-3 Miscellaneous Tank Assembly
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	852522	Screw	3	
2	187213	Washer - Lock.....	3	
3	165627	Washer	3	
4	779451	Bracket - Entrance	1	
5	943683	Clip - Wash Tank	1	
6	621276	Stiffener - Tank Wall	2	

Figure 8-3 Miscellaneous Tank Assembly
Order by Part Number



H104_0234DCA
P104_0234DA

Figure 8-4 Electrical Box Slides
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	523016	Nut.....	10	
2	187213	Washer - Lock.....	10	
3	165627	Washer.....	10	
4	955623	Slide Assembly - Electrical Box.....	2	
5	852982	Screw	10	

Figure 8-4 Electrical Box Slides
Order by Part Number

BLANK PAGE

SECTION 9 Numerical Index

Part Number	Description	Figure Number
		2-3
136224	E-Ring.....	7-2
139941	Fuse - A1 F1, 5 Amp, 250 volts	6-3
144097	Nut - Wing	3-3, 3-4, 5-1,
165627	Washer	7-1, 7-2,
		8-3, 8-4
		7-2
165678	Screw.....	7-7
168424	Washer - Lock.....	7-7
173865	Nut - Lock, 3/4-in.....	7-3
180271	Screw.....	6-7
180281	Fitting - T.....	2-5, 2-6
182399	Bearing	3-27
182590	Tie.....	3-3, 3-4,
183322	Screw.....	3-10, 3-12,
		3-13, 3-19,
		3-21, 3-22,
		3-27, 3-32,
		3-35, 3-41
		5-1, 7-1, 7-2,
187213	Washer - Lock.....	8-3, 8-4
		4-1
187235	Screw.....	3-3, 3-4
187283	Washer - Lock.....	7-6
191097	Screw.....	2-4, 5-1, 7-1,
191098	Washer - Lock.....	7-5, 7-6
		4-1
192904	E-Ring.....	3-36
1C0983	Roller - Squeegee, Drive.....	3-36
1C0985	Roller - Squeegee, Driven.....	3-32
1C0998	Bracket - Tubing.....	7-1
1C4042	Guard - Splash.....	3-32
1C4384	Tube - Yoke Supply	3-32
1C4385	Hose - Yoke.....	3-32
1C4391	Manifold - Water.....	3-25, 3-30,
1C4392	Side Plate - Wash, Non-Drive Side	3-31
		2-7
1C4393	Cover - Wet Section.....	3-32
1C4398	Assembly - Tubing.....	6-6
1C4519	Fitting - Bulkhead, 5/8-inch	6-6
1C4520	Fitting - Bulkhead, 3/8-inch	6-6
1C4523	Fitting - Bulkhead, 1-inch	6-6
1C4721	Washer - Rubber, 5/8-inch.....	3-36
1C4952	Shaft - Drive	3-28
1C4962	Rack - Wash.....	6-9
1C4968	Valve - Dole, 3/4 gal/min.....	3-12, 3-13,
1C7106	Spring - Extension.....	3-17, 3-21,
		3-22, 3-42,
		3-43

Part Number	Description	Figure Number
1C7107	Spring - Extension	3-25, 3-26, 3-30, 3-31
1C7381	Roller	3-6, 3-8, 3-15, 3-17
1C7399	Yoke and Pin Assembly	3-27, 3-32
209234	Screw	7-3
227322	Battery	7-4
240101	Air Tube - Metal	3-34, 3-35
241883	Block - Terminal	7-2
243572	Block - Terminal	7-2
246580	Spring	3-36
246800	Clamp - Hose	6-7, 6-8, 6-9
246801	Clamp - Hose	6-7, 6-8
246803	Clamp - Hose	6-7, 6-8, 6-9
246804	Clamp - Hose	6-9
246805	Clamp - Hose	6-9
246808	Clamp - Hose	6-7, 6-8
246979	Roller	3-15, 3-16, 3-24, 3-25, 3-26, 3-29, 3-30, 3-31, 3-42, 3-43
246981	Shaft	3-7, 3-16
246982	Shaft	3-25, 3-26, 3-30, 3-31
246984	Washer	2-4
264405	Holder - Fuse, Buss	7-2
264407	Fuse - F3 and F4, 2 Amp	7-2
273691	Fuse - F1, 2.5 Amp	7-2
288235	Plate - Nut	2-4, 2-5, 7-1, 7-5
292888	Jack - ESD, Ground	7-2
324726	Latch Assembly	2-1
333951	Tubing - Formed	6-7, 6-8
335500	Connector - J502	7-2
335656	Roller - Squeegee, Driven	3-34
335657	Roller - Squeegee, Drive	3-34
3B7301	Bearing - Thrust	3-36
418700	Housing - Inner	6-3
418701	Housing and Impeller Assembly	6-3
418775	Washer - Thrust	3-3, 3-4, 3-7, 3-9, 3-12, 3-13, 3-16, 3-18, 3-21, 3-22, 3-25, 3-26, 3-30, 3-31, 3-36, 3-37, 3-42
452990	Tubing - Replenishment	8-2
453342	O-Ring	3-27
454454	Sprocket - Drive	4-2

Part Number	Description	Figure Number
458170	Rod - Tie.....	3-2, 3-3, 3-4, 3-12, 3-13, 3-21, 3-22
458175	Shaft	3-3, 3-4
458219	Rod - Tie.....	3-10, 3-19, 3-27, 3-32
458394	Rod - Tie.....	3-41
458953	Guide Shoe.....	3-2, 3-3, 3-4, 3-12, 3-13
459229	Screw - Leveling.....	8-1
459432	Tray - Drip	8-2
459548	Plate - Floor.....	8-1
459576	Orifice	6-8
459943	Washer - I/D Developer	3-10
459944	Washer - I/D	3-19
459946	Washer - I/D	3-12
459947	Washer - I/D	3-21
463363	O-Ring	6-3
467843	Spring	3-7, 3-16
472261	Strainer Assembly	8-2
472592	Rocker - Bearing	3-3, 3-4
472605	Housing - Left Side	6-3
472606	Housing - Right Side	6-3
472755	Nut - Special N-D, Short	3-4, 3-13, 3-22
472756	Nut - Special D, Long.....	3-3, 3-12, 3-21
473926	Magnet.....	6-3
474180	Support	3-3, 3-4
474362	Impeller	6-3
474596	Bracket - Film Guide Shoe.....	3-10, 3-12, 3-13, 3-19, 3-21, 3-22, 3-27, 3-32, 3-35, 3-41
475493	Block - Hinge.....	7-1
477011	Fitting - Y	6-7
477506	Cap - Fuse Holder.....	7-2
478510	Fitting - Elbow.....	6-2
479821	Graduate - Cylinder.....	8-2
480820	Screw.....	7-6
483051	Washer	7-7
486480	Fitting - Elbow.....	6-7
489174	Washer - Rubber, 3/8-inch.....	6-6
489997	Standoff - Pivot.....	3-3, 3-4
490108	Roller - Detector	3-2, 3-3
490109	Roller - Detector	3-2, 3-3
493505	Washer	6-3
498607	Holder - Fuse.....	7-2
498941	Magnet - Actuator.....	2-4, 2-5, 7-5
499754	Connector - Hose	6-6

Part Number	Description	Figure Number
502464	Pin.....	3-3, 3-7, 3-9, 3-12, 3-16, 3-17, 3-18, 3-21, 3-25, 3-26, 3-30, 3-31, 3-36, 3-37, 3-38
520388	O-Ring	6-4
520390	Fitting - Elbow.....	6-4
520391	Nut	6-4
523016	Nut	8-4
531927	Clamp	5-1
532008	Bellows	6-4
532108	Sleeve - Blower, Outlet	5-1
532124	Gear - Snap-In.....	3-38
532164	Bar - Tie.....	3-35
532378	O-Ring	6-1
532379	Washer	6-1
534770	Deflector - Air Tube	3-35
535039	Screw.....	7-2
535638	Body - Valve	6-4
535639	O-Ring	6-4
541891	Plug - Thermowell	6-2
542087	Rod Assembly	2-6
542088	Catch Assembly.....	2-6
544070	Gear.....	3-36
544081	Pin.....	3-36
544132	Screw.....	3-7
544194	Screw.....	3-3, 3-4, 7-5
550774	Gear.....	3-7, 3-16, 3-36
550781	Gear - Drive, Crossover	3-3, 3-12, 3-21, 3-25, 3-30
556032	Screw - Detector.....	2-4, 5-1, 7-1, 7-5
562226	Washer	3-7, 3-9, 3-16, 3-18
562228	Stud - Snap-In	3-3, 3-4, 3-8, 3-17, 3-37, 3-38
562330	Roller	3-3, 3-4
562389	Guide Shoe.....	3-12, 3-13, 3-21, 3-22
562500	Spring	3-9, 3-18
562609	Spring - Air Tube.....	3-35
562615	Gear - 20-Tooth.....	3-43
562650	Shield.....	4-1
562765	Guide Shoe.....	3-10, 3-19
575820	Screw.....	7-5
575821	Screw.....	2-4, 3-3, 3-4, 7-5, 3-39

Part Number	Description	Figure Number
575822	Washer	2-4, 3-3, 3-4, 7-1, 7-5, 7-6 3-34, 3-38
587329	Roller	4-1
594103	Retainer - Bearing	3-3, 3-4,
594229	Shaft	3-12, 3-13, 3-21, 3-22 3-12, 3-13, 3-21, 3-22
594230	Shaft	3-3, 3-4, 3-12, 3-13, 3-21, 3-22
594233	Bracket - Film Guide Shoe.....	3-3, 3-4, 3-12, 3-13, 3-21, 3-22
594236	Shaft	3-9, 3-18
594237	Roller	3-6, 3-7, 3-13, 3-15, 3-16, 3-17, 3-22, 3-42, 3-43 3-9, 3-18
594240	Bushing	3-9, 3-18
594241	Gear	3-9, 3-18
594242	Shaft	3-6, 3-9
594243	Roller	3-15, 3-18
594244	Roller	3-8, 3-17,
594248	Gear - Snap-In.....	3-38
594251	Gear - Snap-In.....	3-8
594252	Sleeve.....	3-9, 3-18
594253	Idler - Chain.....	3-9, 3-18
594254	Gear.....	3-7, 3-16, 3-17
594255	Bushing	3-7
594261	Sprocket.....	3-7, 3-16
594271	Roller - Rewet.....	3-6, 3-7, 3-15, 3-16
594273	Bearing	3-7, 3-16
594288	Roller	3-6, 3-8, 3-15, 3-17
594291	Gear - Gudgeon, Compound	3-8, 3-17
594297	Gear - Idler	3-7
594320	Screw.....	3-9, 3-18
594534	Washer	6-9
594535	Gasket	6-9
594782	Connector - Panel	7-7
594838	Cup - Displacement.....	6-4
595426	Bearing	4-1
597341	Fuse - F2, 8 Amp	7-2
607748	Thermowell	6-2
607793	Locator.....	6-2
609817	Valve - Poppet.....	6-4
610000	Standoff	7-1
613122	Cover - Evaporation	2-7
613246	Sprocket.....	3-9, 3-18

Part Number	Description	Figure Number
619284	Screw.....	2-3, 2-4, 4-1, 4-2, 5-1, 7-5, 7-7
619512	Washer - Thrust.....	3-36
621276	Stiffener - Tank Wall	8-3
650707	Bearing	3-3, 3-4
650876	Actuator - Magnet.....	3-3, 3-4
650938	Gasket - Lighttight, 10 ft roll.....	8-2
651107	E-Ring.....	3-3, 3-4, 3-7, 3-9, 3-12, 3-13, 3-16, 3-17, 3-18, 3-21, 3-22, 3-25, 3-26, 3-30, 3-31, 3-36, 3-37, 3-38, 3-42
655290	Relay - Solid State	7-2
696090	Side Plate - Drive Side.....	3-42
696091	Side Plate - Non-Drive Side.....	3-42
696092	Rack - Exit, Top	3-1, 3-40
696093	Rack - Dryer	3-1, 3-33
696156	Board - Universal Film Detector, 5600	7-1
696159	Board - Display, 300	7-5
696165	Heater - Solution	6-2
699551	PROM - Bootstrap.....	7-4
719488	Symbol - Corporate	2-1
728326	Screw - Jack.....	7-3
740639	Nut - Wing	6-5
740721	O-Ring	6-5
748021	Shaft	3-37
748022	Shaft	3-38
748023	Bracket - Dryer Thermistor/Thermostat	7-6
748024	Bracket - Over-Temperature Thermostat.....	7-6
748043	Washer - Sealing.....	7-5
748131	Relay - K1.....	7-2
748501	Autotransformer	7-7
748511	Heater - Dryer.....	5-1
748512	Jack - Interface, Phone.....	7-3
748638	Blower Assembly - Dryer	5-1
748875	Roller	3-6, 3-9, 3-15, 3-18
748955	Gear - Worm, Left-hand.....	4-1
748956	Gear - Worm, Right-hand.....	4-1
748957	Washer	4-1
779028	Gear.....	3-25, 3-26, 3-30, 3-31
779070	Side Plate - Wash, Non-Drive Side	3-26
779101	Rack - Wash.....	3-1

Part Number	Description	Figure Number
779119	Bearing	3-3, 3-4, 3-7, 3-9, 3-12, 3-13, 3-16, 3-17, 3-18, 3-21, 3-22, 3-25, 3-30, 3-36, 3-37, 3-38
779325	Gear Box	4-2
779330	Mandrel - Developer, Red	6-5
779333	Housing - Film Detector	7-1
779334	Chain - Roller	3-7, 3-9, 3-16, 3-18
779335	Label - Identification	2-1
779336	Bin - Receiving, Film Exit	2-1
779342	Recirculation Pump Assembly	6-3
779344	Solenoid - Cooling	6-7
779345	Side Plate - Wash, Drive Side	3-25, 3-26, 3-30, 3-31
779347	Bar - Spray	3-27
779348	Inlet - Bar, Spray	3-27
779349	Guard - Splash	3-23
779355	Mount - Bar, Spray	3-27
779358	Panel - Bulkhead	6-6
779359	Valve - Drain, Blue	6-6
779362	Tubing - Formed	6-9
779363	Tubing - Formed	6-7, 6-8
779364	Tubing - Formed	6-7
779365	Tubing - Formed	6-8, 6-9
779366	Tubing - Formed	6-7, 6-8
779368	Tubing - Formed	6-7, 6-8
779370	Tubing - Straight	6-7
779373	Fitting - Bulkhead, 3/8 inch	6-7, 6-8
779376	Nut - Jam, 3/8 - 20	6-6, 6-7, 6-8
779377	Nut - Jam, 5/8 - 16	6-6
779378	Nut - Jam, 1-inch - 12	6-6
779382	Tubing - Formed	6-7
779383	Tubing - Formed	6-7
779384	Tubing - Formed	6-7
779385	Tubing - Straight	6-7
779387	Tubing - Formed	6-7
779388	Tubing - Formed	6-7, 6-8
779389	Cover - Drive Chain Guard	4-2
779393	Panel - Exit	2-1
779394	Panel - Access, Non-Drive Side	2-1
779395	Panel - Feed End	2-2
779396	Panel - Access, Drive Side	2-2
779397	Panel - Safelight	7-5
779398	Panel - Access, Feed End	2-2
779400	Strip - Terminal, TB2 and TB3	7-7
779401	Insulator	7-7
779406	Fuse - F5, 0.15 Amp	7-2
779409	Transformer - 16 VAC	7-2

Part Number	Description	Figure Number
779428	Block - Terminal	7-7
779431	Side Plate - Developer, Non-Drive Side	3-7, 3-8
779432	Side Plate - Developer, Drive Side	3-7, 3-8
779433	Side Plate - Detector Crossover, Drive Side	3-3
779434	Side Plate - Detector Crossover, Non-Drive Side	3-4
779435	Side Plate - Crossover	3-12, 3-13, 3-21, 3-22
779438	Quencharc	7-2
779451	Bracket - Entrance	8-3
779454	Cover - Cable	7-5
779458	Housing - Level Sensor, Developer	7-5
779459	Probe - Level Sensor	7-5
779464	Tubing - Straight	6-8
779466	Tubing - Formed	3-27
779468	Valve - Drain, Red	6-6
779473	Housing - Level Sensor, Fixer	7-5
779660	Tubing - Formed	6-8
779732	Board - Control Interface, 200	7-3
781405	Receptacle - Safelight	7-3
785462	Coil	7-2
838999	Gear - Idler	3-16
851269	Washer - Star	7-7
852522	Screw	5-1, 7-1, 7-5, 8-3, 3-32
852523	Screw	7-7
852558	Setscrew	4-2
852611	Washer	3-3, 3-4, 3-7, 3-9, 5-1, 7-2, 7-6, 7-7, 3-16, 3-18
852616	Washer	2-3, 2-4, 4-1, 4-2, 5-1, 7-7, 3-39
852682	Screw	3-3, 3-4, 5-1, 3-27, 3-32, 3-41
852698	Screw	2-4, 2-6
852774	Screw	7-3, 7-5
852800	Nut	4-2
852802	Screw	7-5
852807	Screw	3-9, 3-10, 3-19
852809	Screw	7-7
852811	Screw	3-35, 3-39
852871	Screw	7-7
852945	Screw	3-39
852946	Screw	6-3
852959	Screw	3-16
852961	Washer - Lock	2-3, 2-4, 4-1, 4-2, 5-1, 7-7
852982	Screw	7-1, 8-4

Part Number	Description	Figure Number
853000	Pin.....	4-1
853080	Nut	3-7, 3-9, 3-16, 3-18
853087	Washer - Lock	3-3, 3-4, 3-7, 3-9, 3-16, 3-18
853096	Washer - Lock	3-3, 3-4
853100	Washer - Lock	5-1, 7-2, 7-6
853141	Screw.....	3-9, 3-18
897205	Bearing - Thrust.....	4-1
902351	Fitting.....	5-1
903739	Shield - Ferrite.....	7-2
911412	Controller - Motor	7-2
911414	Display	7-5
911432	Thermistor - Solution.....	6-2
911433	Thermistor - Dryer	7-6
911651	Shaft	3-24, 3-25, 3-29, 3-30
911653	Shaft	3-42, 3-43
911656	Shaft - Drive	4-1
911660	Roller	3-22, 3-24, 3-25, 3-26, 3-29, 3-30, 3-31, 3-34, 3-36, 3-37, 3-38, 3-42, 3-43
911661	Roller	3-6, 3-8
911662	Roller	3-34, 3-37
911663	Gear.....	3-17, 3-37
911664	Gear.....	3-36, 3-37, 3-38
911674	Adaptor - Exhaust.....	5-1
911675	Plenum - Air Return	5-1
911676	Hose	5-1
911678	Adapter - Plenum End.....	5-1
911682	Rod - Tie.....	3-41
911683	Nut - Special.....	3-41
911684	Bearing	3-42
911689	Block - Hinge Plate	2-4
911691	Screw - Shoulder.....	3-43
911692	Deflector - Rack.....	3-9
911707	Cover - Autotransformer.....	2-7
911708	Cover - Splash.....	2-7
911713	Bracket - Hinge.....	2-3
911714	Plate - Hinge, Drive Side	2-3
911715	Plate - Hinge, Non-Drive Side.....	2-3
911716	Pin - Hinge.....	2-3
911717	Hinge - Nut Plate.....	2-3
911719	Spring - Hinge, Drive Side	2-3
911720	Spring - Hinge, Non-Drive Side	2-3
911724	Screw - Shoulder.....	3-25, 3-26, 3-30, 3-31

Part Number	Description	Figure Number
911725	Bushing - Idle	3-25, 3-26, 3-30, 3-31
911727	Chain - Drive	4-1, 4-2
911730	Plate - Top Cover, Hinge	2-5, 2-6
911731	Mount - Bearing, Feed End.....	4-1
911732	Shim.....	4-1
911735	Bracket - Plenum.....	5-1
911748	Guide Shoe.....	3-41
911749	Guide Shoe.....	3-41
914518	Screw.....	4-2
914547	Motor.....	4-2
914596	Filter - EMI.....	7-7
914599	Switch - Detector	2-4, 2-5, 7-1, 7-5
914701	Guide Shoe.....	3-21, 3-22
914703	Guide Shoe.....	3-10, 3-19, 3-27, 3-32
914704	Guide Shoe.....	3-35
914706	Cover - Plenum Assembly	5-1
914712	Cover - Dryer, Front	3-39
914719	Mandrel - Fixer, Blue.....	6-5
914721	Sprocket - Drive.....	4-1
914722	Bracket - Dryer Thermistor.....	7-6
914723	Plate.....	5-1
914724	Exchanger - Heat	6-1
914728	Ring - Pull.....	7-2
914731	Orifice .250 inches.....	6-7
914732	Orifice .125 inches.....	6-7
914736	Sprocket.....	3-36
914737	Chain	3-36
914738	Chain	3-40
914742	Cover - Top Exit Rack.....	5-1
914744	Screen - Heater.....	3-27, 3-32
914745	Clip - Stand-off	2-2
914747	Shelf - Feed.....	3-35
914875	Bracket - Captive.....	2-5, 2-6
914883	Pin - Hinge, Top Cover	7-2, 7-5
914888	Fan.....	2-1, 2-2
914891	Panel - Side, Stand	2-2
914892	Panel - Rear, Stand	2-1
914893	Panel - Front, Stand.....	8-1
914894	Seismic Bracket Kit for processors without a stand.....	8-1
914895	Seismic Bracket Kit for processors with a stand	4-1
914898	Pin - Dowel.....	7-3
914899	Panel - Control Interface	6-7, 6-8, 6-9
914908	Clamp - Hose	7-5
914912	Screw.....	2-4
914915	Spindle - Stop, Cushion	2-4
914917	Plate - Stop.....	3-11
914920	Trough - Crossover, Developer/Fixer.....	3-34, 3-35
914921	Air Tube - Snouted, Black.....	3-20
914922	Trough - Crossover, Fixer/Wash.....	7-5
918094	Button - Replenishment Switch Assembly	

Part Number	Description	Figure Number
918343	Breaker - Circuit, 20 Amps.....	7-3
918383	Label - Caution.....	5-1
918929	Spacer	7-2
918931	Cover - Chain, Drive	3-39
918938	Rack - Developer.....	3-1, 3-5
918939	Rack - Fixer.....	3-1, 3-14
918943	Crossover - Detector	3-1, 3-2
918944	Crossover - Developer/Fixer	3-1, 3-11
918945	Crossover - Fixer/Wash.....	3-1, 3-20
918947	Guard - Splash	8-2
943375	Switch - Dryer, Airflow.....	5-1
943378	Varistor - Metal Oxide	7-2
943400	Bracket - Switch	5-1
943419	Pin - Hinge.....	2-4
943427	Cover - Relay	7-2
943429	Cover - Power Supply	7-2
943435	Coil.....	7-2
943441	Roller	3-15, 3-17, 3-42, 3-43
943442	Filter - Cartridge, Developer.....	6-5
943444	Guard - Transformer.....	7-2
943445	Shield - Film Detector	7-1
943466	Side Plate - Fixer, Non-Drive Side.....	3-16
943467	Side Plate - Fixer, Drive Side	3-16
943468	Shaft	3-17
943469	Gudgeon - Snap-In.....	3-38
943471	Bushing.....	3-16
943473	Shaft	3-7, 3-16
943662	Plenum - Dryer	3-39
943663	Bearing	2-4
943665	Tubing - Straight.....	6-9
943666	Valve - Water Solenoid	6-9
943668	Tubing Formed	6-9
943676	Panel - Safelight.....	7-3
943683	Clip - Wash Tank	8-3
943686	Latch - Cover.....	2-4
943700	Coupling - Insert.....	3-27
943701	Disconnect - Water.....	6-9
943903	Strip - Marker.....	7-7
955595	Bracket - Stop, Non-Drive	3-39
955596	Bracket - Stop, Drive.....	3-39
955598	Mask - Display.....	7-5
955623	Slide Assembly - Electrical Box	8-4
955719	Switch - Replenishment Calibrate.....	7-5
955736	Replenishment Pump Assembly	6-4
955741	Thermostat - Dryer, Over-Temperature	7-6
955745	Power Supply - DC, Quad	7-2
963541	Valve - Dole, 1 gal/min.....	6-9
968736	Shaft	3-34, 3-36
968740	Tubing - Formed.....	3-27
968748	Board - 600.....	7-2
968795	Plate - Hinge.....	2-4
968796	Roller	3-6, 3-7

Part Number	Description	Figure Number
968797	Tray - Receive	2-1
968798	Cover - Top	2-1
981759	Board - Microprocessor, 500.....	7-2, 7-4
981892	Bracket - Detector Switch, Non-Drive Side.....	7-1
981893	Bracket - Detector Switch, Drive Side	7-1
981894	Locator.....	3-9
990002	Side Plate - Drive Side.....	3-37
990003	Side Plate - Non-Drive Side.....	3-37
990010	Screw - Shoulder.....	3-37, 3-42
990014	Roller	3-42
990015	Roller	3-42
990019	Shaft	3-25, 3-26, 3-30, 3-31
990021	Mount - Bearing, Dryer End.....	4-1
990029	PROM - U12.....	7-1
990032	EEPROM Set - Main/Language Other Languages.....	7-4
990035	EEPROM Set - Main/Language Japanese	7-4
990327	Gear.....	3-42
990418	Plug - Gland Sealing	6-1

SECTION 10

Alphabetical Index

Part Number	Description	Figure Number
650876	Actuator - Magnet.....	3-3, 3-4
911678	Adapter - Plenum End.....	5-1
911674	Adaptor - Exhaust.....	5-1
240101	Air Tube - Metal	3-34, 3-35
914921	Air Tube - Snouted, Black.....	3-34, 3-35
1C4398	Assembly - Tubing.....	3-32
748501	Autotransformer	7-7
779347	Bar - Spray	3-27
532164	Bar - Tie.....	3-35
227322	Battery	7-4
182399	Bearing	2-5, 2-6
594273	Bearing	3-7, 3-16
595426	Bearing	4-1
650707	Bearing	3-3, 3-4
779119	Bearing	3-3, 3-4, 3-7, 3-9, 3-12, 3-13, 3-16, 3-17, 3-18, 3-21, 3-22, 3-25, 3-30, 3-36, 3-37, 3-38
911684	Bearing	3-42
943663	Bearing	2-4
3B7301	Bearing - Thrust.....	3-36
897205	Bearing - Thrust.....	4-1
532008	Bellows	6-4
779336	Bin - Receiving, Film Exit.....	2-1
475493	Block - Hinge	7-1
911689	Block - Hinge Plate	2-4
241883	Block - Terminal	7-2
243572	Block - Terminal	7-2
779428	Block - Terminal	7-7
748638	Blower Assembly - Dryer	5-1
968748	Board - 600.....	7-2
779732	Board - Control Interface, 200	7-3
696159	Board - Display, 300	7-5
981759	Board - Microprocessor, 500.....	7-2, 7-4
696156	Board - Universal Film Detector, 5600	7-1
535638	Body - Valve	6-4
914875	Bracket - Captive	3-35
981893	Bracket - Detector Switch, Drive Side	7-1
981892	Bracket - Detector Switch, Non-Drive Side.....	7-1
914722	Bracket - Dryer Thermistor.....	7-6
748023	Bracket - Dryer Thermistor/Thermostat	7-6
779451	Bracket - Entrance.....	8-3

Part Number	Description	Figure Number
474596	Bracket - Film Guide Shoe.....	3-10, 3-12, 3-13, 3-19, 3-21, 3-22, 3-27, 3-32, 3-35, 3-41
594233	Bracket - Film Guide Shoe.....	3-3, 3-4, 3-12, 3-13, 3-21, 3-22
911713	Bracket - Hinge.....	2-3
748024	Bracket - Over-Temperature Thermostat.....	7-6
911735	Bracket - Plenum.....	5-1
955596	Bracket - Stop, Drive.....	3-39
955595	Bracket - Stop, Non-Drive.....	3-39
943400	Bracket - Switch.....	5-1
1C0998	Bracket - Tubing.....	3-32
918343	Breaker - Circuit, 20 Amps.....	7-3
594240	Bushing.....	3-9, 3-18
594255	Bushing.....	3-7
943471	Bushing.....	3-16
911725	Bushing - Idle.....	3-25, 3-26, 3-30, 3-31
918094	Button - Replenishment Switch Assembly.....	7-5
477506	Cap - Fuse Holder.....	7-2
542088	Catch Assembly.....	2-6
914737	Chain.....	3-36
914738	Chain.....	3-36
911727	Chain - Drive.....	4-1, 4-2
779334	Chain - Roller.....	3-7, 3-9, 3-16, 3-18
531927	Clamp.....	5-1
246800	Clamp - Hose.....	6-7, 6-8, 6-9
246801	Clamp - Hose.....	6-7, 6-8
246803	Clamp - Hose.....	6-7, 6-8, 6-9
246804	Clamp - Hose.....	6-9
246805	Clamp - Hose.....	6-9
246808	Clamp - Hose.....	6-7, 6-8
914908	Clamp - Hose.....	6-7, 6-8, 6-9
914745	Clip - Stand-off.....	3-27, 3-32
943683	Clip - Wash Tank.....	8-3
785462	Coil.....	7-2
943435	Coil.....	7-2
499754	Connector - Hose.....	6-6
335500	Connector - J502.....	7-2
594782	Connector - Panel.....	7-7
911412	Controller - Motor.....	7-2
943700	Coupling - Insert.....	3-27
911707	Cover - Autotransformer.....	2-7
779454	Cover - Cable.....	7-5
918931	Cover - Chain, Drive.....	3-39
779389	Cover - Drive Chain Guard.....	4-2
914712	Cover - Dryer, Front.....	3-39
613122	Cover - Evaporation.....	2-7
914706	Cover - Plenum Assembly.....	5-1

Part Number	Description	Figure Number
943429	Cover - Power Supply	7-2
943427	Cover - Relay	7-2
911708	Cover - Splash.....	2-7
968798	Cover - Top	2-1
914742	Cover - Top Exit Rack.....	3-40
1C4393	Cover - Wet Section.....	2-7
918943	Crossover - Detector	3-1, 3-2
918944	Crossover - Developer/Fixer	3-1, 3-11
918945	Crossover - Fixer/Wash.....	3-1, 3-20
594838	Cup - Displacement.....	6-4
534770	Deflector - Air Tube.....	3-35
911692	Deflector - Rack.....	3-9
943701	Disconnect - Water.....	6-9
911414	Display	7-5
136224	E-Ring.....	2-3
192904	E-Ring.....	4-1
651107	E-Ring.....	3-3, 3-4, 3-7, 3-9, 3-12, 3-13, 3-16, 3-17, 3-18, 3-21, 3-22, 3-25, 3-26, 3-30, 3-31, 3-36, 3-37, 3-38, 3-42
990035	EEPROM Set - Main/Language Japanese	7-4
990032	EEPROM Set - Main/Language Other Languages.....	7-4
914724	Exchanger - Heat	6-1
914888	Fan.....	7-2, 7-5
943442	Filter - Cartridge, Developer.....	6-5
914596	Filter - EMI.....	7-7
902351	Fitting	5-1
1C4523	Fitting - Bulkhead, 1-inch	6-6
779373	Fitting - Bulkhead, 3/8 inch	6-7, 6-8
1C4520	Fitting - Bulkhead, 3/8-inch	6-6
1C4519	Fitting - Bulkhead, 5/8-inch	6-6
478510	Fitting - Elbow.....	6-2
486480	Fitting - Elbow.....	6-7
520390	Fitting - Elbow.....	6-4
180281	Fitting - T	6-7
477011	Fitting - Y	6-7
139941	Fuse - A1 F1, 5 Amp, 250 volts	7-2
273691	Fuse - F1, 2.5 Amp	7-2
597341	Fuse - F2, 8 Amp	7-2
264407	Fuse - F3 and F4, 2 Amp	7-2
779406	Fuse - F5, 0.15 Amp	7-2
594535	Gasket	6-9
650938	Gasket - Lighttight, 10 ft roll.....	8-2
544070	Gear.....	3-36
550774	Gear.....	3-7, 3-16, 3-36
594241	Gear.....	3-9, 3-18

Part Number	Description	Figure Number
594254	Gear.....	3-7, 3-16, 3-17
779028	Gear.....	3-25, 3-26, 3-30, 3-31
911663	Gear.....	3-17, 3-37
911664	Gear.....	3-36, 3-37, 3-38
990327	Gear.....	3-42
562615	Gear - 20-Tooth.....	3-43
550781	Gear - Drive, Crossover.....	3-3, 3-12, 3-21, 3-25, 3-30
594291	Gear - Gudgeon, Compound.....	3-8, 3-17
594297	Gear - Idler.....	3-7
838999	Gear - Idler.....	3-16
532124	Gear - Snap-In.....	3-38
594248	Gear - Snap-In.....	3-8, 3-17, 3-38
594251	Gear - Snap-In.....	3-8
748955	Gear - Worm, Left-hand.....	4-1
748956	Gear - Worm, Right-hand.....	4-1
779325	Gear Box.....	4-2
479821	Graduate - Cylinder.....	8-2
1C4042	Guard - Splash.....	7-1
779349	Guard - Splash.....	3-23
918947	Guard - Splash.....	8-2
943444	Guard - Transformer.....	7-2
943469	Gudgeon - Snap-In.....	3-38
458953	Guide Shoe.....	3-2, 3-3, 3-4, 3-12, 3-13
562389	Guide Shoe.....	3-12, 3-13, 3-21, 3-22
562765	Guide Shoe.....	3-10, 3-19
911748	Guide Shoe.....	3-41
911749	Guide Shoe.....	3-41
914701	Guide Shoe.....	3-21, 3-22
914703	Guide Shoe.....	3-10, 3-19, 3-27, 3-32
914704	Guide Shoe.....	3-35
748511	Heater - Dryer.....	5-1
696165	Heater - Solution.....	6-2
911717	Hinge - Nut Plate.....	2-3
498607	Holder - Fuse.....	7-2
264405	Holder - Fuse, Buss.....	7-2
911676	Hose.....	5-1
1C4385	Hose - Yoke.....	3-32
779333	Housing - Film Detector.....	7-1
418700	Housing - Inner.....	6-3
472605	Housing - Left Side.....	6-3
779458	Housing - Level Sensor, Developer.....	7-5
779473	Housing - Level Sensor, Fixer.....	7-5
472606	Housing - Right Side.....	6-3
418701	Housing and Impeller Assembly.....	6-3

Part Number	Description	Figure Number
		3-9, 3-18
594253	Idler - Chain.....	6-3
474362	Impeller.....	3-27
779348	Inlet - Bar, Spray.....	7-7
779401	Insulator.....	7-2
292888	Jack - ESD, Ground.....	7-3
748512	Jack - Interface, Phone.....	5-1
918383	Label - Caution.....	2-1
779335	Label - Identification.....	2-4
943686	Latch - Cover.....	2-1
324726	Latch Assembly.....	6-2
607793	Locator.....	3-9
981894	Locator.....	6-3
473926	Magnet.....	2-4, 2-5, 7-5
498941	Magnet - Actuator.....	6-5
779330	Mandrel - Developer, Red.....	6-5
914719	Mandrel - Fixer, Blue.....	3-32
1C4391	Manifold - Water.....	7-5
955598	Mask - Display.....	4-2
914547	Motor.....	3-27
779355	Mount - Bar, Spray.....	4-1
990021	Mount - Bearing, Dryer End.....	4-1
911731	Mount - Bearing, Feed End.....	6-4
520391	Nut.....	8-4
523016	Nut.....	4-2
852800	Nut.....	3-7, 3-9,
853080	Nut.....	3-16, 3-18
		6-6
779378	Nut - Jam, 1-inch - 12.....	6-6, 6-7, 6-8
779376	Nut - Jam, 3/8 - 20.....	6-6
779377	Nut - Jam, 5/8 - 16.....	7-7
173865	Nut - Lock, 3/4-in.....	3-41
911683	Nut - Special.....	3-3, 3-12,
472756	Nut - Special D, Long.....	3-21
		3-4, 3-13,
472755	Nut - Special N-D, Short.....	3-22
		6-3
144097	Nut - Wing.....	6-5
740639	Nut - Wing.....	3-27
453342	O-Ring.....	6-3
463363	O-Ring.....	6-4
520388	O-Ring.....	6-1
532378	O-Ring.....	6-4
535639	O-Ring.....	6-5
740721	O-Ring.....	6-8
459576	Orifice.....	6-7
914732	Orifice .125 inches.....	6-7
914731	Orifice .250 inches.....	7-4
699551	PROM - Bootstrap.....	7-1
990029	PROM - U12.....	2-2
779396	Panel - Access, Drive Side.....	2-2
779398	Panel - Access, Feed End.....	2-1
779394	Panel - Access, Non-Drive Side.....	6-6
779358	Panel - Bulkhead.....	

Part Number	Description	Figure Number
914899	Panel - Control Interface	7-3
779393	Panel - Exit	2-1
779395	Panel - Feed End	2-2
914893	Panel - Front, Stand	2-1
914892	Panel - Rear, Stand	2-2
779397	Panel - Safelight	7-5
943676	Panel - Safelight	7-3
914891	Panel - Side, Stand	2-1, 2-2
502464	Pin	3-3, 3-7, 3-9, 3-12, 3-16, 3-17, 3-18, 3-21, 3-25, 3-26, 3-30, 3-31, 3-36, 3-37, 3-38
544081	Pin	3-36
853000	Pin	4-1
914898	Pin - Dowel	4-1
911716	Pin - Hinge	2-3
943419	Pin - Hinge	2-4
914883	Pin - Hinge, Top Cover	2-5, 2-6
914723	Plate	5-1
459548	Plate - Floor	8-1
968795	Plate - Hinge	2-4
911714	Plate - Hinge, Drive Side	2-3
911715	Plate - Hinge, Non-Drive Side	2-3
288235	Plate - Nut	2-4, 2-5, 7-1, 7-5
914917	Plate - Stop	2-4
911730	Plate - Top Cover, Hinge	2-5, 2-6
911675	Plenum - Air Return	5-1
943662	Plenum - Dryer	3-39
990418	Plug - Gland Sealing	6-1
541891	Plug - Thermowell	6-2
955745	Power Supply - DC, Quad	7-2
779459	Probe - Level Sensor	7-5
779438	Quencharc	7-2
918938	Rack - Developer	3-1, 3-5
696093	Rack - Dryer	3-1, 3-33
696092	Rack - Exit, Top	3-1, 3-40
918939	Rack - Fixer	3-1, 3-14
1C4962	Rack - Wash	3-28
779101	Rack - Wash	3-1
781405	Receptacle - Safelight	7-3
779342	Recirculation Pump Assembly	6-3
748131	Relay - K1	7-2
655290	Relay - Solid State	7-2
955736	Replenishment Pump Assembly	6-4
594103	Retainer - Bearing	4-1
914728	Ring - Pull	7-2
472592	Rocker - Bearing	3-3, 3-4

Part Number	Description	Figure Number
458170	Rod - Tie.....	3-2, 3-3, 3-4, 3-12, 3-13, 3-21, 3-22
458219	Rod - Tie.....	3-10, 3-19, 3-27, 3-32
458394	Rod - Tie.....	3-41
911682	Rod - Tie.....	3-41
542087	Rod Assembly	2-6
1C7381	Roller	3-6, 3-8, 3-15, 3-17
246979	Roller	3-15, 3-16, 3-24, 3-25, 3-26, 3-29, 3-30, 3-31, 3-42, 3-43
562330	Roller	3-3, 3-4
587329	Roller	3-34, 3-38
594237	Roller	3-6, 3-7, 3-13, 3-15, 3-16, 3-17, 3-22, 3-42, 3-43
594243	Roller	3-6, 3-9
594244	Roller	3-15, 3-18
594288	Roller	3-6, 3-8, 3-15, 3-17
748875	Roller	3-6, 3-9, 3-15, 3-18
911660	Roller	3-22, 3-24, 3-25, 3-26, 3-29, 3-30, 3-31, 3-34, 3-36, 3-37, 3-38, 3-42, 3-43
911661	Roller	3-6, 3-8
911662	Roller	3-34, 3-37
943441	Roller	3-15, 3-17, 3-42, 3-43
968796	Roller	3-6, 3-7
990014	Roller	3-42
990015	Roller	3-42
490108	Roller - Detector	3-2, 3-3
490109	Roller - Detector	3-2, 3-3
594271	Roller - Rewet.....	3-6, 3-7, 3-15, 3-16
1C0983	Roller - Squeegee, Drive.....	3-36
335657	Roller - Squeegee, Drive.....	3-34
1C0985	Roller - Squeegee, Driven.....	3-36
335656	Roller - Squeegee, Driven.....	3-34
914744	Screen - Heater.....	5-1
165678	Screw.....	7-2
180271	Screw.....	7-3

Part Number	Description	Figure Number
183322	Screw.....	3-3, 3-4, 3-10, 3-12, 3-13, 3-19, 3-21, 3-22, 3-27, 3-32, 3-35, 3-41
187235	Screw.....	4-1
191097	Screw.....	7-6
209234	Screw.....	7-3
480820	Screw.....	7-6
535039	Screw.....	7-2
544132	Screw.....	3-7
544194	Screw.....	3-3, 3-4, 7-5
575820	Screw.....	7-5
575821	Screw.....	2-4, 3-3, 3-4, 7-5, 3-39
594320	Screw.....	3-9, 3-18
619284	Screw.....	2-3, 2-4, 4-1, 4-2, 5-1, 7-5, 7-7
852522	Screw.....	5-1, 7-1, 7-5, 8-3, 3-32
852523	Screw.....	7-7
852682	Screw.....	3-3, 3-4, 5-1, 3-27, 3-32, 3-41
852698	Screw.....	2-4, 2-6
852774	Screw.....	7-3, 7-5
852802	Screw.....	7-5
852807	Screw.....	3-9, 3-10, 3-19
852809	Screw.....	7-7
852811	Screw.....	3-35, 3-39
852871	Screw.....	7-7
852945	Screw.....	3-39
852946	Screw.....	6-3
852959	Screw.....	3-16
852982	Screw.....	7-1, 8-4
853141	Screw.....	3-9, 3-18
914518	Screw.....	4-2
914912	Screw.....	7-5
556032	Screw - Detector.....	2-4, 5-1, 7-1, 7-5
728326	Screw - Jack.....	7-3
459229	Screw - Leveling.....	8-1
911691	Screw - Shoulder.....	3-43
911724	Screw - Shoulder.....	3-25, 3-26, 3-30, 3-31
990010	Screw - Shoulder.....	3-37, 3-42
914895	Seismic Bracket Kit for processors with a stand.....	8-1
914894	Seismic Bracket Kit for processors without a stand.....	8-1
852558	Setscrew.....	4-2
246981	Shaft.....	3-7, 3-16

Part Number	Description	Figure Number
246982	Shaft	3-25, 3-26, 3-30, 3-31
458175	Shaft	3-3, 3-4
594229	Shaft	3-3, 3-4, 3-12, 3-13, 3-21, 3-22
594230	Shaft	3-12, 3-13, 3-21, 3-22
594236	Shaft	3-9, 3-18
594242	Shaft	3-9, 3-18
748021	Shaft	3-37
748022	Shaft	3-38
911651	Shaft	3-24, 3-25, 3-29, 3-30
911653	Shaft	3-42, 3-43
943468	Shaft	3-17
943473	Shaft	3-7, 3-16
968736	Shaft	3-34, 3-36
990019	Shaft	3-25, 3-26, 3-30, 3-31
1C4952	Shaft - Drive	3-36
911656	Shaft - Drive	4-1
914747	Shelf - Feed	2-2
562650	Shield	4-1
903739	Shield - Ferrite	7-2
943445	Shield - Film Detector	7-1
911732	Shim	4-1
779435	Side Plate - Crossover	3-12, 3-13, 3-21, 3-22
779433	Side Plate - Detector Crossover, Drive Side	3-3
779434	Side Plate - Detector Crossover, Non-Drive Side	3-4
779432	Side Plate - Developer, Drive Side	3-7, 3-8
779431	Side Plate - Developer, Non-Drive Side	3-7, 3-8
696090	Side Plate - Drive Side	3-42
990002	Side Plate - Drive Side	3-37
943467	Side Plate - Fixer, Drive Side	3-16
943466	Side Plate - Fixer, Non-Drive Side	3-16
696091	Side Plate - Non-Drive Side	3-42
990003	Side Plate - Non-Drive Side	3-37
779345	Side Plate - Wash, Drive Side	3-25, 3-26, 3-30, 3-31
1C4392	Side Plate - Wash, Non-Drive Side	3-25, 3-30, 3-31
779070	Side Plate - Wash, Non-Drive Side	3-26
594252	Sleeve	3-9, 3-18
532108	Sleeve - Blower, Outlet	5-1
955623	Slide Assembly - Electrical Box	8-4
779344	Solenoid - Cooling	6-7
918929	Spacer	7-2
914915	Spindle - Stop, Cushion	2-4
246580	Spring	3-36
467843	Spring	3-7, 3-16
562500	Spring	3-9, 3-18

Part Number	Description	Figure Number
562609	Spring - Air Tube	3-35
1C7106	Spring - Extension	3-12, 3-13, 3-17, 3-21, 3-22, 3-42, 3-43
1C7107	Spring - Extension	3-25, 3-26, 3-30, 3-31
911719	Spring - Hinge, Drive Side	2-3
911720	Spring - Hinge, Non-Drive Side	2-3
594261	Sprocket	3-7, 3-16
613246	Sprocket	3-9, 3-18
914736	Sprocket	3-36
454454	Sprocket - Drive	4-2
914721	Sprocket - Drive	4-1
610000	Standoff	7-1
489997	Standoff - Pivot	3-3, 3-4
621276	Stiffener - Tank Wall	8-3
472261	Strainer Assembly	8-2
943903	Strip - Marker	7-7
779400	Strip - Terminal, TB2 and TB3	7-7
562228	Stud - Snap-In	3-3, 3-4, 3-8, 3-17, 3-37, 3-38
474180	Support	3-3, 3-4
914599	Switch - Detector	2-4, 2-5, 7-1, 7-5
943375	Switch - Dryer, Airflow	5-1
955719	Switch - Replenishment Calibrate	7-5
719488	Symbol - Corporate	2-1
911433	Thermistor - Dryer	7-6
911432	Thermistor - Solution	6-2
955741	Thermostat - Dryer, Over-Temperature	7-6
607748	Thermowell	6-2
182590	Tie	3-27
779409	Transformer - 16 VAC	7-2
459432	Tray - Drip	8-2
968797	Tray - Receive	2-1
914920	Trough - Crossover, Developer/Fixer	3-11
914922	Trough - Crossover, Fixer/Wash	3-20
1C4384	Tube - Yoke Supply	3-32
333951	Tubing - Formed	6-7, 6-8
779362	Tubing - Formed	6-9
779363	Tubing - Formed	6-7, 6-8
779364	Tubing - Formed	6-7
779365	Tubing - Formed	6-8, 6-9
779366	Tubing - Formed	6-7, 6-8
779368	Tubing - Formed	6-7, 6-8
779382	Tubing - Formed	6-7
779383	Tubing - Formed	6-7
779384	Tubing - Formed	6-7
779387	Tubing - Formed	6-7
779388	Tubing - Formed	6-7, 6-8
779466	Tubing - Formed	3-27

Part Number	Description	Figure Number
779660	Tubing - Formed.....	6-8
968740	Tubing - Formed.....	3-27
452990	Tubing - Replenishment.....	8-2
779370	Tubing - Straight.....	6-7
779385	Tubing - Straight.....	6-7
779464	Tubing - Straight.....	6-8
943665	Tubing - Straight.....	6-9
943668	Tubing Formed.....	6-9
963541	Valve - Dole, 1 gal/min.....	6-9
1C4968	Valve - Dole, ¾ gal/min.....	6-6
779359	Valve - Drain, Blue.....	6-6
779468	Valve - Drain, Red.....	6-4
609817	Valve - Poppet.....	6-9
943666	Valve - Water Solenoid.....	7-2
943378	Varistor - Metal Oxide.....	3-3, 3-4, 5-1,
165627	Washer.....	7-1, 7-2,
		8-3, 8-4
		2-4
246984	Washer.....	7-7
483051	Washer.....	6-3
493505	Washer.....	6-1
532379	Washer.....	3-7, 3-9,
562226	Washer.....	3-16, 3-18
		2-4, 3-3, 3-4,
575822	Washer.....	7-1, 7-5,
		7-6
		6-9
594534	Washer.....	4-1
748957	Washer.....	3-3, 3-4, 3-7,
852611	Washer.....	3-9, 5-1,
		7-2, 7-6,
		7-7, 3-16,
		3-18
		2-3, 2-4, 4-1,
852616	Washer.....	4-2, 5-1,
		7-7, 3-39
		3-19
459944	Washer - I/D.....	3-12
459946	Washer - I/D.....	3-21
459947	Washer - I/D.....	3-10
459943	Washer - I/D Developer.....	7-7
168424	Washer - Lock.....	5-1, 7-1, 7-2,
187213	Washer - Lock.....	8-3, 8-4
		3-3, 3-4
187283	Washer - Lock.....	2-4, 5-1, 7-1,
191098	Washer - Lock.....	7-5, 7-6
		2-3, 2-4, 4-1,
852961	Washer - Lock.....	4-2, 5-1,
		7-7
		3-3, 3-4, 3-7,
853087	Washer - Lock.....	3-9, 3-16,
		3-18

Part Number	Description	Figure Number
853096	Washer - Lock	3-3, 3-4
853100	Washer - Lock	5-1, 7-2, 7-6
489174	Washer - Rubber, 3/8-inch	6-6
1C4721	Washer - Rubber, 5/8-inch	6-6
748043	Washer - Sealing	7-5
851269	Washer - Star	7-7
418775	Washer - Thrust	3-3, 3-4, 3-7, 3-9, 3-12, 3-13, 3-16, 3-18, 3-21, 3-22, 3-25, 3-26, 3-30, 3-31, 3-36, 3-37, 3-42
619512	Washer - Thrust	3-36
1C7399	Yoke and Pin Assembly	3-27, 3-32

SECTION 11
Publication Change Table

Revision Date	ECO No.	PCN No.	PCN Pub. No.	Affected Pages	Filename	Description
October 1993	2592-210	1	2B6844	All	3059ip_b.txt	Supersedes Publication No. 636717. Updates part numbers and illustrations throughout.
May 1994	2592-265	2	2B6844	3, 2-3 - 2-5, 2-15, 3-1, 3-11, 3-15, 3-23, 3-25, 3-27, 3-31, 3-39, 3-41 - 3-77, 6-3, 6-13, 6-14, 6-16, 6-19, 7-3, 7-5, 7-7, 7-11, 7-15, and the indices and covers	3059ip_b_rev1.txt	Adds Mod 17 parts for the Wash Rack, and updates part numbers and illustrations throughout.

Health Sciences
EASTMAN KODAK COMPANY
Rochester, New York 14650

Kodak and X-Omat are trademarks.

Printed on recycled paper containing 10% post-
consumer waste fiber, using soybean-based inks.

The new vision of Kodak

